

Fuel System

GENERAL	FL - 2
MFI CONTROL SYSTEM	FL -20
FUEL DELIVERY SYSTEM	FL -59
TROUBLESHOOTING FOR DTC	FL -70

GENERAL

SPECIFICATIONS IFTC0010

Items	Specifications
Fuel tank Capacity Fuel filter Fuel pump Throttle body Throttle position sensor (TP Sensor) Resistance Output voltage at idle	35 lit. (9.2 U.S. gal., 7.7 Imp.gal.) High pressure type Electrical, in-tank type Variable resistor type 0.7 - 3.0 k Ω 0.1 - 0.875V
Input sensors Manifold absolute pressure (MAP) sensor Type Output voltage Knock sensor Intake Air Temperature sensor (IAT Sensor) Resistance EVAP Canister Purge solenoid valve Resistance Engine coolant temperature sensor (ECT Sensor) Resistance Oxygen sensor (O2S) Output voltage (V) Vehicle speed sensor Camshaft position sensor (CMP Sensor) Output voltage (V) Crankshaft position sensor (CKP Sensor) Output frequency (Hz)	Piezo-Resistivity type 0 - 5V Piezoelectric type Thermistor type 2.0 - 3.0 k Ω at 20°C (68°F) Duty type 26 Ω Thermistor type 1.0 - 4.0k Ω at 20°C (68°F) 0.24 - 0.40k Ω at 80°C (176°F) Zirconia sensor (Heated) 0 - 1V Reed switch type Hall effect sensor 0 - 5V Magnetic inductive type Idle rpm : 750 - 950Hz 3000 rpm : 2700 - 3300Hz
Output actuators Injector Type Number Coil resistance (Ω) Fuel pressure regulator Regulator pressure Idle speed control actuator (ISC Actuator) Type Control frequency (Hz)	Electromagnetic type 4 15.9 \pm 0.35 Ω 350 kPa (3.5 kg/cm ² , 49.8 psi) Double coil type 100Hz

SERVICE STANDARD

Items		Standard value
Basic ignition timing		BTDC 8° \pm 5°
Curb idle speed (rpm)	Normal	850 \pm 100
	Electrical load	900 \pm 100
	A/con ON	900 \pm 100
	Electrical load & A/con ON	1000 \pm 100


SEALANT

Engine coolant temperature sensor assembly Engine coolant temperature sender	LOCTITE 962T or equivalent Three bond No.2310 or equivalent
---	--

TIGHTENING TORQUE

Items	Nm	Kg·cm	lb·ft
Delivery pipe installation bolts	10 - 15	100 - 150	7 - 11
Oxygen sensor	50 - 60	500 - 600	37 - 44
Crankshaft position sensor installation bolts	9 - 11	90 - 110	7 - 8
Knock sensor installation bolt	16 - 25	160 - 250	12 - 18
Engine coolant temperature sensor	15 - 20	150 - 200	11 - 15
Throttle position sensor installation bolts	1.5 - 2.5	15 - 25	1.1 - 1.8
Throttle body to surge tank bolts	15 - 20	150 - 200	11 - 15

SPECIAL TOOLS EFTC0030

Tool (Number and name)	Illustration	Application
09353-24100 Fuel pressure gauge & hose	 <p style="text-align: right; font-size: small;">C5324100</p>	Connection of fuel pressure gauge to delivery pipe for measurement of fuel pressure.
09353-02000 Quick connector remover	 <p style="text-align: right; font-size: small;">C5302000</p>	Remover of quick connector in delivery pipe and return pipe.
09353-02100 Fuel pressure gauge adaptor	 <p style="text-align: right; font-size: small;">C5302100</p>	Use with fuel pressure gauge when measuring the fuel pressure.

BASIC TROUBLESHOOTING EFDA0050

When checking for engine trouble, it is important to start with an inspection of the basic systems. If one of the following conditions exists; (A) engine start failure, (B) unstable idling or (C) poor acceleration, begin by checking the following basic systems:

1. Power supply
 - Battery
 - Fusible link
 - Fuse
2. Body ground
3. Fuel supply
 - Fuel line
 - Fuel filter
 - Fuel pump
4. Ignition system
 - Spark plug
 - High-tension cable
 - Ignition coil
5. Emission control system
 - PCV system
 - Vacuum leak
6. Others
 - Ignition timing
 - Idle speed

Trouble with the MFI system is often caused by poor contact of the harness connectors. It is important to check all harness connectors and verify that they are securely connected.

TROUBLESHOOTING GUIDE CHART IFDA0070

Main Symptoms Sub-Symptoms Check points	STARTING							Poor Idling					Poor Driving	
	Unable to start			Difficult to start				Incorrect fast idle	High idle speed	Low idle speed	Rough idling	Engine hesitates or accelerates poorly	Surging	Knocking
	Engine does not turn over	Starter runs but engine does not turn over	Incomplete combustion	Engine turns over	Always	When the engine is cold	When the engine is hot							
Starter	2	2		1										
Park/Neutral SW [A/T] or Clutch start SW [M/T]	3													
Flywheel [M/T] or Drive plate [A/T]		4												
Mass air flow sensor circuit			3						3	10	7			
Idle speed control actuator			4		3	3	3	3	2	7			2	
Fuel pressure regulator			5		5	5				4	11	1		
ECT sensor circuit			6		4	1	1	2	2	1	2	8	6	
Compression			7		8					8	5			
Piston rings			8		9					9				
Ignition timing					10					11	14			
Timing mark			9							12				
Injectors			10		13	8	8		7	4	13	15	4	
ECM			11		14	9	9	4	8	5	14	16	5	
A/C circuit				2					6					
Connecting rod bearing				3										
Crankshaft bearing				4										
Fuel quality					1	2	2				1	3	3	
Spark plugs					2						3	4	2	
Fuel pump					6	6	6				5	12		
Fuel lines					7	7	7				6	13		
Ignition circuit			2		11								3	
Intake air temp. sensor circuit					12	4	4		4			9	1	
Accelerator pedal link								1	1					
TP Sensor circuit									5			6		
Cylinder head										15				
Clutch [M/T]												1		
Brakes not releasing properly												2		
Oxygen sensor circuit												10		
Crankshaft position sensor		3												
Battery voltage		1	1											

Main Symptoms Sub-Symptoms Check points	Engine Stalls				Others		
	Soon after starting	After accelerator pedal is depressed	After accelerator pedal is released	During A/C ON	Excessive fuel consumption	Engine overheats	Engine too cool
Fuel quality	1						
Fuel pressure regulator	2	4			2		
Fuel pump	3						
Fuel lines	4	5					
ISC actuator	5		1	2			
MAP sensor circuit	6	1	2		13		
ECT sensor circuit	7				11		
Injectors	8	6			10		
ECM	9	7	3	3	17		
TP Sensor circuit		2			12		
Spark plug		3			6	8	
A/C circuit				1	14		
Fuel leakage					1		
Accelerator pedal link					3		
Clutch [M/T]					4		
Brakes drag when pedal released					5		
Compression					7		
Piston ring					8		
Ignition timing					9		
Oxygen sensor circuit					15		
Intake air temp. sensor circuit					16		
Coolant leakage						1	
Cooling fan						2	1
Thermo switch						3	
Radiator and radiator cap						4	2
Thermostat						5	
Timing belt						6	
Engine coolant pump						7	
Oil pump						9	
Cylinder head						10	
Cylinder block						11	
ECT sender						12	3
Crankshaft position sensor	11	8	4	4			

 **NOTE**

The number herein means the check order.

SERVICE ADJUSTMENT PROCEDURES

EFTC0090

IDLE SPEED

NOTE

Before adjusting, check that the spark plugs, injectors, idle speed control actuator (ISC actuator), compression etc. are normal.

CHECK CONDITIONS

- Engine coolant temperature is 80 to 95°C (176 to 205°F).
 - Lights, electric cooling fan and all accessories are off.
 - Transaxle is in neutral ("P" or "N" range for A/T vehicles).
 - Steering wheel is in a straight forward position (Vehicles with power steering).
1. Install a tachometer to the primary coil side or connect the scan tool to the data link connector.
 2. Start and run the engine at curb idle speed.
 3. Run the engine for more than 5 seconds at an engine speed of 2,000 to 3,000 rpm. Then, run the engine at idle for 2 minutes.
 4. Read the idling rpm.

Idle speed	850 ± 100 rpm
------------	---------------


FUEL PUMP OPERATING CHECK

EFTC0110

1. Turn the ignition switch OFF.
2. Apply battery voltage to the fuel pump drive connector to check that the pump operates.


NOTE

The fuel pump is an in-tank type and its operation is hard to hear without removing the fuel tank cap.



T7FL005A

3. Pinch the hose to check that fuel pressure is felt.




T7FL006A

FUEL PRESSURE TEST EFTC0130

- Reduce the internal pressure of the fuel pipes and hoses by the following procedures.
 - Disconnect the fuel pump harness connector.
 - Start the engine and after it stops by itself, turn the ignition switch to the OFF position.
 - Disconnect the battery negative (-) terminal.
 - Connect the fuel pump harness connector.
- Remove the upper eye bolt while holding the fuel filter nut securely.

CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by fuel residual pressure in the fuel line.




EFTC013A

- Using the fuel pressure gauge adapter (09353-24000, 09353-24100, 09353-24200), install the fuel-pressure gauge to the fuel filter. Tighten the bolt to the specified torque.

Tightening Torque

Fuel pressure gauge to fuel filter :


25 - 35 Nm (250 - 350 kg·cm, 18 - 26 lb·ft)



T7FL008A

- Connect the battery's negative (-) terminal.
- Apply battery voltage to the terminal for the pump drive and activate the fuel pump: then, with fuel pressure applied, check that there is no fuel leakage from the pressure gauge or connection part.
- Start the engine and let it idle.
- Disconnect the vacuum hose from the pressure regulator, and plug the hose end. Measure the fuel pressure.


Standard valve : 300 kPa (3.06 kg/cm², 44.37 psi)



T7FL009A

- Measure the fuel pressure when the vacuum hose is connected to the pressure regulator.

Standard valve : Approx. 255 kPa (2.57 kg/cm², 37 psi)



T7FL008A

- If the results of the measurements made in steps (6) and (7) are not within the standard valve, use the below table to determine the probable cause, and make the necessary repairs.

Condition	Probable cause	Remedy
Fuel pressure too low	a. Clogged fuel filter. b. Fuel leak on the return side, caused by poor seating of the fuel-pressure regulator. c. Low discharge pressure of the fuel pump	a. Replace fuel filter. b. Replace fuel pressure regulator. c. Check the in-tank fuel hose for leakage or replace the fuel pump.
Fuel pressure too high	a. Sticking fuel-pressure regulator. b. Clogged or bent fuel return hose or pipe.	a. Replace fuel pressure regulator. b. Repair or replace hose or pipe.
There is no difference in fuel pressure when the vacuum hose is connected and when it is not.	a. Clogging, or damaged vacuum hose or the nipple. b. Sticking or poor seating of the fuel pressure regulator.	a. Repair or replace the vacuum hose or the nipple b. Repair or replace hose or pipe.

10. Stop the engine and check for a change in the fuel pressure gauge reading, which should hold for approximately 5 minutes. If the gauge indication drops, observe the rate of drop. Determine and remove the causes according to the following table.

Condition	Probable cause	Remedy
Fuel pressure drops slowly after engine is stopped	a. Injector leakage	a. Replace injector
Fuel pressure drops immediately after engine is stopped	a. The check valve within the fuel pump is open	a. Replace fuel pump

11. Reduce the pressure in the fuel line.

12. Disconnect the hose and the gauge.

 **CAUTION**

Cover on the hose connection with a shop towel to prevent splashing of fuel caused by fuel residual pressure in the fuel line.

13. Replace the O-ring of the end of the hose.

14. Connect the fuel hose to the delivery pipe and tighten with the specified torque.

15. Check for fuel leakage.

MFI SYSTEM INSPECTION IFTD0150

If the MFI system components (sensors, ECM, injector, etc.) fail, interruption to the fuel supply or failure to supply the proper amount of fuel for various engine operating conditions will result. The following situations may be encountered.

1. Engine is hard to start or does not start at all.
2. Unstable idle.
3. Poor driveability

If any of the above conditions are noted, first perform a routine diagnosis that includes basic engine checks (ignition system malfunction, incorrect engine adjustment, etc.). Then, inspect the MFI system components with the HI-SCAN.

**NOTE**

- Before removing or installing any part, read the diagnostic trouble codes and then disconnect the battery negative (-) terminal.
- Before disconnecting the cable from battery terminal, turn the ignition switch to OFF. Removal or connection of the battery cable during engine operation or while the ignition switch is ON could cause damage to the ECM.
- The control harnesses between the ECM and heated oxygen sensor are shielded with the shielded ground wires to the body in order to prevent the influence of ignition noises and radio interference. When the shielded wire is faulty, the control harness must be replaced.
- When checking the generator for the charging state, do not disconnect the battery '+' terminal to prevent the ECM from damage due to the voltage.
- When charging the battery with the external charger, disconnect the vehicle side battery terminals to prevent damage to the ECM.

MALFUNCTION INDICATOR LAMP (MIL) (IF INSTALLED)**[EOBD]**

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turn on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL

- Catalyst
- Fuel system
- Manifold absolute pressure sensor (MAP sensor)
- Intake Air Temperature Sensor
- Engine Coolant Temperature Sensor
- Throttle Position Sensor
- Upstream Oxygen Sensor
- Downstream Oxygen Sensor Heater
- Downstream Oxygen Sensor
- Upstream Oxygen Sensor Heater
- Injector
- Misfire
- Crankshaft Position Sensor
- Camshaft Position Sensor
- Evaporative Emission Control System
- Vehicle Speed Sensor
- Idle Control Valve
- Power Supply
- ECM
- MT/AT Encoding
- Acceleration Sensor
- MIL-on Request Signal
- Power Stage

[EXCEPT EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turn on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL

- Oxygen sensor (O2S)
- Manifold absolute pressure sensor (MAP sensor)
- Throttle position sensor (TP Sensor)
- Engine coolant temperature sensor (ECT Sensor)
- Idle speed control actuator (ISC Actuator)
- Injectors
- ECM

INSPECTION

1. After turning ON the ignition key, ensure that the light illuminates for about 5 seconds and then goes out.
2. If the light does not illuminate, check for an open circuit in the harness, a blown fuse or a blown bulb.


SELF-DIAGNOSIS

The ECM monitors the input/output signals (some signals at all times and the others under specified conditions). When the ECM detects an irregularity, it records the diagnostic trouble code, and outputs the signal to the Data Link connector. The diagnosis results can be read with the HI-SCAN. Diagnostic trouble codes (DTC) will remain in the ECM as long as battery power is maintained. The diagnostic trouble codes will, however, be erased when the battery terminal or the engine control module (ECM) connector is disconnected or by HI-CAN.

 **NOTE**

If a sensor connector is disconnected with the ignition switch turned on, the diagnostic trouble code (DTC) is recorded. In this case, disconnect the battery negative terminal (-) for 15 seconds or more, and the diagnosis memory will be erased.

THE RELATION BETWEEN DTC AND DRIVING PATTERN IN EOBD SYSTEM (IF INSTALLED) EFTC0170



EFDA017A

1. When the same malfunction is detected and maintained during two sequential driving cycles, the MIL will automatically illuminate.
2. The MIL will go off automatically if no fault is detected after 3 sequential driving cycles.
3. A Diagnostic Trouble Code(DTC) is recorded in ECM memory when a malfunction is detected after two sequential driving cycles. The MIL will illuminate when the malfunction is detected on the second driving cycle.
If a misfire is detected, a DTC will be recorded, and the MIL will illuminate, immediately after a fault is first detected.
4. A diagnostic Trouble Code(DTC) will automatically erase from ECM memory if the same malfunction is not detected for 40 driving cycles.

NOTE

- A "warm-up cycle" means sufficient vehicle operation such that the coolant temperature has risen by at least 40 degrees Fahrenheit from engine starting and reaches a minimum temperature of 160 degrees Fahrenheit.
- A "driving cycle" consists of engine startup, vehicle operation beyond the beginning of closed loop operation.

INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES

EFTD0190

[EOBD, BOSCH EMS]

DTC NO.	DESCRIPTION	MIL
P0030	O2 Sensor Heater - Heater Control Circuit Malfunction (Bank 1 / Sensor 1)	O
P0031	O2 Sensor Heater Circuit Low (Bank 1 / Sensor 1)	O
P0032	O2 Sensor Heater Circuit High (Bank 1 / Sensor 1)	O
P0036	O2 Sensor Heater - Heater Control Circuit Malfunction (Bank 1 / Sensor 2)	O
P0037	O2 Sensor Heater Circuit Low (Bank 1 / Sensor 2)	O
P0038	O2 Sensor Heater Circuit High (Bank 1 / Sensor 2)	O
P0106	Manifold Absolute Pressure (MAP) Sensor Circuit Rationality	O
P0107	Manifold Absolute Pressure (MAP) Sensor Circuit Low Input	O
P0108	Manifold Absolute Pressure (MAP) Sensor Circuit High Input	O
P0112	Intake Air Temperature (IAT) Sensor Circuit Low Input	O
P0113	Intake Air Temperature (IAT) Sensor Circuit High Input	O
P0116	Engine Coolant Temperature (ETC) Sensor Circuit Range / Performance	O
P0117	Engine Coolant Temperature (ETC) Sensor Circuit Low Input	O
P0118	Engine Coolant Temperature (ETC) Sensor Circuit High Input	O
P0121	Throttle Position Sensor (TPS) Circuit Range / Performance Problem	O
P0122	Throttle Position Sensor (TPS) Circuit Low Input	O
P0123	Throttle Position Sensor (TPS) Circuit High Input	O
P0130	O2 Sensor Circuit Malfunction (Bank 1 / Sensor 1)	O
P0131	O2 Sensor Circuit Malfunction Low Input (Bank 1 / Sensor 1)	O
P0132	O2 Sensor Circuit High Input (Bank 1 / Sensor 1)	O
P0133	O2 Sensor Circuit Slow Response (Bank 1 / Sensor 1)	O
P0134	O2 Sensor Circuit No Activity Detected (Bank 1 / Sensor 1)	O
P0136	O2 Sensor Circuit Malfunction (Bank 1 / Sensor 2)	O
P0137	O2 Sensor Circuit Low Input (Bank 1 / Sensor 2)	O
P0138	O2 Sensor Circuit High Input (Bank 1 / Sensor 2)	O
P0140	O2 Sensor Circuit No Activity Detected (Bank 1 / Sensor 2)	O
P0261	Cylinder 1 - Injector Circuit Low	O
P0262	Cylinder 1 - Injector Circuit High	O
P0264	Cylinder 2 - Injector Circuit Low	O
P0265	Cylinder 2 - Injector Circuit High	O
P0267	Cylinder 3 - Injector Circuit Low	O
P0268	Cylinder 3 - Injector Circuit High	O
P0270	Cylinder 4 - Injector Circuit Low	O
P0271	Cylinder 4 - Injector Circuit High	O
P0300	Multiple Cylinder Misfire Detected	O

DTC NO.	DESCRIPTION	MIL
P0301	Cylinder 1 - Misfire detected	O
P0302	Cylinder 2 - Misfire detected	O
P0303	Cylinder 3 - Misfire detected	O
P0304	Cylinder 4 - Misfire detected	O
P0325	Knock Sensor 1 Circuit Malfunction (Bank 1)	X
P0335	Crankshaft Position (CKP) Sensor Circuit Malfunction	O
P0336	Crankshaft Position (CKP) Sensor Circuit Range Random	O
P0340	Camshaft Position (CMP) Sensor Circuit Malfunction	O
P0420	Catalyst System Efficiency Below Threshold (Bank 1)	O
P0444	Evap. Emission Control System - Purge Control Valve Circuit Open	O
P0445	Evap. Emission Control System - Purge Control Valve Circuit Shorted	O
P0501	Vehicle Speed Sensor (VSS) Range / Performance	O
P0506	Idle Control System - RPM Lower Than Expected	O
P0507	Idle Control System - RPM Higher Than Expected	O
P0562	System Voltage Low	O
P0563	System Voltage High	O
P0605	Internal Control Module Read Only Memory (ROM)	O
P0650	Malfunction Indicator Lamp(MIL) Control Circuit	X
P1307	Acceleration Sensor Circuit Rationality	O
P1308	Acceleration Sensor Circuit Low	O
P1309	Acceleration Sensor Circuit High	O
P1505	Idle Air Actuator Signal Low of Coil #1	O
P1506	Idle Air Actuator Signal High of Coil #1	O
P1507	Idle Air Actuator Signal Low of Coil #2	O
P1508	Idle Air Actuator Signal High of Coil #2	O
P1586	Encoding Signal Circuit Not Rational	O
P1690	Smartra Error	X
P1691	Immobilizer Antena Error	X
P1693	Immobilizer Transponder Error	X
P1694	Immobilizer ECM Siganl Error	X
P1695	Immobilizer EEPROM Error	X
P1696	Immobilizer Mismatch / Overtrial Error	X
P2187	System Too Lean At Idle - Addition	O
P2188	System Too Rich At Idle - Addition	O
P2191	System Too Lean At Idle - Multiple	O
P2192	System Too Rich At Idle - Multiple	O

INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES

EFTD0210

[MEXICO, BOSCH EMS]

DTC NO.	DESCRIPTION	MIL
P0031	O2 Sensor Heater Circuit Low (Bank 1 / Sensor 1)	X
P0032	O2 Sensor Heater Circuit High (Bank 1 / Sensor 1)	X
P0107	Manifold Absolute Pressure (MAP) Sensor Circuit Low Input	O
P0108	Manifold Absolute Pressure (MAP) Sensor Circuit High Input	O
P0112	Intake Air Temperature (IAT) Sensor Circuit Low Input	X
P0113	Intake Air Temperature (IAT) Sensor Circuit High Input	X
P0117	Engine Coolant Temperature (ETC) Sensor Circuit Low Input	O
P0118	Engine Coolant Temperature (ETC) Sensor Circuit High Input	O
P0122	Throttle Position Sensor (TPS) Circuit Low Input	O
P0123	Throttle Position Sensor (TPS) Circuit High Input	O
P0131	O2 Sensor Circuit Malfunction Low Input (Bank 1 / Sensor 1)	X
P0132	O2 Sensor Circuit High Input (Bank 1 / Sensor 1)	X
P0133	O2 Sensor Circuit Slow Response (Bank 1 / Sensor 1)	X
P0261	Cylinder 1 - Injector Circuit Low	O
P0262	Cylinder 1 - Injector Circuit High	O
P0264	Cylinder 2 - Injector Circuit Low	O
P0265	Cylinder 2 - Injector Circuit High	O
P0267	Cylinder 3 - Injector Circuit Low	O
P0268	Cylinder 3 - Injector Circuit High	O
P0270	Cylinder 4 - Injector Circuit Low	O
P0271	Cylinder 4 - Injector Circuit High	O
P0325	Knock Sensor 1 Circuit Malfunction (Bank 1)	X
P0335	Crankshaft Position (CKP) Sensor Circuit Malfunction	X
P0336	Crankshaft Position (CKP) Sensor Circuit Range Random	X
P0340	Camshaft Position (CMP) Sensor Circuit Malfunction	X
P0501	Vehicle Speed Sensor (VSS) Range / Performance	X
P0506	Idle Control System - RPM Lower Than Expected	X
P0507	Idle Control System - RPM Higher Than Expected	X
P0562	System Voltage Low	X
P0563	System Voltage High	X
P0605	Internal Control Module Read Only Memory (ROM)	X
P1505	Idle Air Actuator Signal Low of Coil #1	O
P1506	Idle Air Actuator Signal High of Coil #1	O
P1507	Idle Air Actuator Signal Low of Coil #2	O
P1508	Idle Air Actuator Signal High of Coil #2	O

DTC NO.	DESCRIPTION	MIL
P1586	Encoding Signal Circuit Not Rational	X
P1690	Smartra Error	X
P1691	Immobilizer Antena Error	X
P1693	Immobilizer Transponder Error	X
P1694	Immobilizer ECM Signal Error	X
P1695	Immobilizer EEPROM Error	X
P1696	Immobilizer Mismatch / Overtrial Error	X
P2187	System Too Lean At Idle - Addition	X
P2188	System Too Rich At Idle - Addition	X
P2191	System Too Lean At Idle - Multiple	X
P2192	System Too Rich At Idle - Multiple	X

INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES

IFTD0220

[NON-EOBO, HMC EMS]

DTC NO.	DESCRIPTION	MIL
P0031	O2 Sensor Heater Circuit Low (Bank 1 / Sensor 1)	X
P0032	O2 Sensor Heater Circuit High (Bank 1 / Sensor 1)	X
P0107	Manifold Absolute Pressure (MAP) Sensor Circuit Low Input	O
P0108	Manifold Absolute Pressure (MAP) Sensor Circuit High Input	O
P0112	Intake Air Temperature (IAT) Sensor Circuit Low Input	X
P0113	Intake Air Temperature (IAT) Sensor Circuit High Input	X
P0117	Engine Coolant Temperature (ETC) Sensor Circuit Low Input	O
P0118	Engine Coolant Temperature (ETC) Sensor Circuit High Input	O
P0122	Throttle Position Sensor (TPS) Circuit Low Input	O
P0123	Throttle Position Sensor (TPS) Circuit High Input	O
P0131	O2 Sensor Circuit Malfunction Low Input (Bank 1 / Sensor 1)	X
P0132	O2 Sensor Circuit High Input (Bank 1 / Sensor 1)	X
P0133	O2 Sensor Circuit Slow Response (Bank 1 / Sensor 1)	X
P0261	Cylinder 1 - Injector Circuit Low	O
P0262	Cylinder 1 - Injector Circuit High	O
P0264	Cylinder 2 - Injector Circuit Low	O
P0265	Cylinder 2 - Injector Circuit High	O
P0267	Cylinder 3 - Injector Circuit Low	O
P0268	Cylinder 3 - Injector Circuit High	O
P0270	Cylinder 4 - Injector Circuit Low	O
P0271	Cylinder 4 - Injector Circuit High	O
P0325	Knock Sensor 1 Circuit Malfunction (Bank 1)	X
P0335	Crankshaft Position (CKP) Sensor Circuit Malfunction	X
P0340	Camshaft Position (CMP) Sensor Circuit Malfunction	X
P0501	Vehicle Speed Sensor (VSS) Range / Performance	X
P1505	Idle Air Actuator Signal Low of Coil #1	O
P1506	Idle Air Actuator Signal High of Coil #1	O
P1507	Idle Air Actuator Signal Low of Coil #2	O
P1508	Idle Air Actuator Signal High of Coil #2	O
P1586	Encoding Signal Circuit Not Rational	X
P1690	Smartra Error	X
P1691	Immobilizer Antena Error	X
P1693	Immobilizer Transponder Error	X
P1694	Immobilizer ECM Siganl Error	X
P1695	Immobilizer EEPROM Error	X
P1696	Immobilizer Mismatch / Overtrial Error	X

INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES


IFTD0221

[INDIA, HEC EMS]

DTC NO.	DESCRIPTION	MIL
P0031	O2 Sensor Heater Circuit Low (Bank 1 / Sensor 1)	X
P0032	O2 Sensor Heater Circuit High (Bank 1 / Sensor 1)	X
P0107	Manifold Absolute Pressure (MAP) Sensor Circuit Low Input	O
P0108	Manifold Absolute Pressure (MAP) Sensor Circuit High Input	O
P0112	Intake Air Temperature (IAT) Sensor Circuit Low Input	X
P0113	Intake Air Temperature (IAT) Sensor Circuit High Input	X
P0117	Engine Coolant Temperature (ETC) Sensor Circuit Low Input	O
P0118	Engine Coolant Temperature (ETC) Sensor Circuit High Input	O
P0122	Throttle Position Sensor (TPS) Circuit Low Input	O
P0123	Throttle Position Sensor (TPS) Circuit High Input	O
P0131	O2 Sensor Circuit Malfunction Low Input (Bank 1 / Sensor 1)	X
P0132	O2 Sensor Circuit High Input (Bank 1 / Sensor 1)	X
P0133	O2 Sensor Circuit Slow Response (Bank 1 / Sensor 1)	X
P0261	Cylinder 1 - Injector Circuit Low	O
P0262	Cylinder 1 - Injector Circuit High	O
P0264	Cylinder 2 - Injector Circuit Low	O
P0265	Cylinder 2 - Injector Circuit High	O
P0267	Cylinder 3 - Injector Circuit Low	O
P0268	Cylinder 3 - Injector Circuit High	O
P0270	Cylinder 4 - Injector Circuit Low	O
P0271	Cylinder 4 - Injector Circuit High	O
P0325	Knock Sensor 1 Circuit Malfunction (Bank 1)	X
P0335	Crankshaft Position (CKP) Sensor Circuit Malfunction	X
P0340	Camshaft Position (CMP) Sensor Circuit Malfunction	X
P0501	Vehicle Speed Sensor (VSS) Range / Performance	X
P1505	Idle Air Actuator Signal Low of Coil #1	O
P1506	Idle Air Actuator Signal High of Coil #1	O
P1507	Idle Air Actuator Signal Low of Coil #2	O
P1508	Idle Air Actuator Signal High of Coil #2	O
P1586	Encoding Signal Circuit Not Rational	X

FUEL FILTER REPLACEMENT EFTC0230

1. Reduce the internal pressure of the fuel lines and hoses by completing the following operations.
 - Disconnect the fuel pump harness connector.
 - Start the engine. Allow it to stop by itself, then turn the ignition switch OFF.
 - Disconnect the battery negative (-) terminal.
 - Connect the fuel pump harness connector.




EFDA023A

2. Remove the eye bolts while holding the fuel filter nuts securely.

CAUTION

Cover the fuel filter with a shop towel to avoid residual gasoline from splashing.


3. Remove the fuel filter mounting bolts, then remove the fuel filter from the fuel filter clamp.
4. After replacing the fuel filter, check for fuel leaks.



T7FL003A


OVERFILL LIMITER (TWO-WAY VALVE) REPLACEMENT EFTC0250

1. Disconnect the vapor hoses, and then remove the overfill limiter.



T7FL020A


2. Connect the overfill limiter in the correct direction.



EFDA025B

FUEL SENDER REPLACEMENT EFTC0270


1. Remove the fuel tank cap to lower the fuel tank's internal pressure.
2. Remove the fuel sender installation screws, then remove the fuel sender from the fuel tank.




T7FL004A

MFI CONTROL SYSTEM

LOCATION OF MFI COMPONENTS IFTD7010














IFTD005A



TFTD005B


- | | |
|--|---|
| <ul style="list-style-type: none"> 1 Air conditioning relay 2 MAP & IAT sensor 3 Idle speed control actuator (ISC Actuator) 4 TPS 5 ECT sensor 6 CMP sensor 7 Injector | <ul style="list-style-type: none"> 8 Oxygen sensor 9 Transaxle range(TR) switch 10 MFI control relay 11 Data link connector 12 Vehicle speed sensor 13 ECM 14 Purge control solenoid valve (PCSV) |
|--|---|

1		2	
 <p>T7FL010B</p>		 <p>T8EC009A</p>	
3		4	
 <p>IFTC723G</p>		 <p>T7FL010D</p>	
5		6	
 <p>T8EC010A</p>		 <p>T7FL010E</p>	
7		8	
 <p>T7FL010F</p>		 <p>T8EC007A</p>	

9		10																																	
 <p style="text-align: right;">T7FL010G</p>		 <p style="text-align: right;">T7FL010H</p>																																	
11		13																																	
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">TCM</th> <th colspan="3" style="text-align: center;">Ground</th> <th colspan="4" style="text-align: center;">Engine</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">8</td> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> </tr> <tr> <td style="text-align: center;">16</td> <td style="text-align: center;">15</td> <td style="text-align: center;">14</td> <td style="text-align: center;">13</td> <td style="text-align: center;">12</td> <td style="text-align: center;">11</td> <td style="text-align: center;">10</td> <td style="text-align: center;">9</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td style="text-align: center;">L-wire</td> <td style="text-align: center;">B+</td> </tr> </tbody> </table> <p style="text-align: right;">IFTC701C</p>		TCM	Ground			Engine				8	7	6	5	4	3	2	1	16	15	14	13	12	11	10	9							L-wire	B+	 <p style="text-align: right;">EFDA301H</p>	
TCM	Ground			Engine																															
8	7	6	5	4	3	2	1																												
16	15	14	13	12	11	10	9																												
						L-wire	B+																												
14																																			
 <p style="text-align: right;">T8EC003A</p>																																			

[HEI ECU]

ECM CONNECTER PIN ARRANGEMENT



ECM PIN NUMBER CONFIGURATION


	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27
28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55

ECM HARNESS PIN NUMBER CONFIGURATION

27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	
55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28

[BOSCH ECU]

ECM PIN NUMBER CONFIGURATION



ECM HARNESS PIN NUMBER CONFIGURATION

1	2	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63
		62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44
	3	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25
4	5	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6

EFDA301Q

[HEI ECU]

ECM PIN NUMBER CONFIGURATION

A	A	A	A	A	A	A	A	A	A	A	A	A	A	B	B	B	B	B	B	B	B	C	C	C	C	C	C	D	D	D	D	D	D	D	D	D	D	D	D	
1	2	3	4	5	6	7	8	9	10	11	12	13	14	1	2	3	4	5	6	7	8	1	2	3	4	5	6	1	2	3	4	5	6	7	8	9	10	11	12	13
A	A	A	A	A	A	A	A	A	A	A	A	A	A	B	B	B	B	B	B	B	B	C	C	C	C	C	C	D	D	D	D	D	D	D	D	D	D	D	D	D
14	15	16	17	18	19	20	21	22	23	24	25	26	27	9	10	11	12	13	14	15	16	7	8	9	10	11	12	12	13	14	15	16	17	18	19	20	21	22	23	24

C01-1

C01-2

C01-3

C04-4

ECM HARNESS PIN NUMBER CONFIGURATION

D	D	D	D	D	D	D	D	D	D	D	C	C	C	C	C	C	B	B	B	B	B	B	B	B	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A										
11	10	9	8	7	6	5	4	3	2	1	6	5	4	3	2	1	8	7	6	5	4	3	2	1	13	12	11	10	9	8	7	6	5	4	3	2	1	2	3	4	5	6	7	8	9	10	11	12		
D	D	D	D	D	D	D	D	D	D	D	C	C	C	C	C	C	B	B	B	B	B	B	B	B	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A		
22	21	20	19	18	17	16	15	14	13	12	12	11	10	9	8	7	16	15	14	13	12	11	10	9	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

C01-4

C01-3


C01-2

C04-1

EFTC301Q


MANIFOLD ABSOLUTE PRESSURE SENSOR (MAP SENSOR) IFTD7070

The manifold absolute pressure (MAP) sensor is a pressure sensitive variable resistor. It measures changes in the intake manifold pressure which result from engine load and speed changes, and converts this to a voltage output. The MAP sensor is also used to measure barometric pressure at start up, and under certain conditions, allows the ECM to automatically adjust for different altitudes. The ECM supplies 5 volts to the MAP sensor and monitors the voltage on a signal line. The sensor provides a path to ground through its variable resistor. The MAP sensor input affects fuel delivery and ignition timing controls in the ECM.



T8EC009A

CIRCUIT DIAGRAM



IFTD707A

TROUBLESHOOTING HINTS

The MIL (Malfunction Indicator Lamp) is ON or the DTC (Diagnostic Trouble Code) is displayed on the HI-SCAN under the following conditions;


1. When the manifold pressure is 118mb or lower for 0.1 second after turning the ignition key ON.
2. When the manifold pressure is 118mb or lower while the RPM is below 1980rpm.
3. When the manifold pressure is 986mb or higher and the rpm is 2400rpm or more while the accelerator pedal is released (such as when a vehicle is moving down on a sloping road).

USING HI-SCAN

Check item	Data display	Check conditions	Engine state	Test specification
MAP sensor	Intake manifold pressure	<ul style="list-style-type: none"> • Engine coolant temperature: 80 to 95° (176 to 205°F) • Lamps, electric cooling fan, accessory units: ALL OFF • Transaxle: Neutral (P range for vehicle with A/T) • Steering wheel: Neutral 	IG. KEY "ON"	850 - 1024 mb
			Idle	260 - 400 mb

HARNESS INSPECTION PROCEDURES

1



Harness side connector

Measure the power supply voltage.

- o Connector : Disconnected
- o Ignition switch : ON
- o Voltage (V) : 4.8 - 5.2V

OK →


NG →

2

Repair the harness.

EFTC707B

2



Harness side connector

Check for an open-circuit, or a short-circuit to ground between the engine control module and the MAP sensor.

- o MAP sensor circuit : Disconnected
- o Engine control module connector : Disconnected

OK →


NG →

3

Repair the harness.

EFTC707C

3



Harness side connector

Check for continuity of the ground circuit.

- o Connector : Disconnected

OK →

NG →

END!

Repair the harness.

EFTC707D

SENSOR INSPECTION


1. Measure the voltage between terminals 1 and 4 of the MAP sensor connectors.
Terminal 1 : MAP sensor output
Terminal 4 : MAP sensor ground

Engine state	Test specification
Ignition SW. ON.	4 - 5V
At idle	0.5 - 2.0V

2. If the voltage deviates from the standard value, replace the MAP sensor assembly.


INTAKE AIR TEMPERATURE SENSOR (IAT SENSOR) IFTD7090

The intake air temperature sensor (IAT Sensor), built in to the MAP sensor, is a resistor-based sensor detect the intake air temperature. According to the intake air temperature information from the sensor, the ECM will control the necessary amount of fuel injection.



T8EC009A

CIRCUIT DIAGRAM



IFTD707A

TROUBLESHOOTING HINTS


The MIL is ON or the DTC is displayed on the HI-SCAN under the following condition;

- When the intake air temperature is detected below -40°C or higher than 120°C.


USING HI-SCAN

Check item	Data display	Check conditions	Engine state	Test specification
Intake air temperature sensor	Air temperature	Ignition switch : ON or engine running	When -20°C (-40°F)	-20°C
			When 0°C (32°F)	0°C
			When 20°C (68°F)	20°C
			When 40°C (104°F)	40°C
			When 80°C (176°F)	80°C

HARNESS INSPECTION PROCEDURES

<div style="border: 1px solid black; padding: 5px; width: 30px; margin: 0 auto;">1</div>  <p style="font-size: small;">Harness side connector</p>	<p>Check for continuity of the ground circuit.</p> <ul style="list-style-type: none"> o Connector disconnected 	<p>OK → <div style="border: 1px solid black; padding: 2px 10px; display: inline-block;">2</div></p> <p>NG → Repair the harness.</p>
--	---	---

IFTC709B

<div style="border: 1px solid black; padding: 5px; width: 30px; margin: 0 auto;">2</div>  <p style="font-size: small;">ECM harness side connector</p> <p style="font-size: small;">Harness side connector</p>	<p>Check for an open-circuit, or a short-circuit to ground between the engine control module and the IAT sensor.</p> <ul style="list-style-type: none"> o ECM connector : Disconnected o IAT sensor connector : Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
--	--	---

IFTC709C

SENSOR INSPECTION


1. Using a multimeter, measure the IAT sensor resistance between terminals 3 and 4.

IG.SW.ON	Temperature °C (°F)	Output voltage (kΩ)
	0 (32)	4.5 - 7.5Ω
	20 (68)	2.0 - 3.0Ω
	40 (104)	0.7 - 1.6Ω
	80 (176)	0.2 - 0.4Ω

2. If the resistance deviates from the standard value, replace the intake air temperature sensor assembly.


ENGINE COOLANT TEMPERATURE SENSOR (ECT SENSOR) IFTD7110

The engine coolant temperature sensor, located in the engine coolant passage of the cylinder head. It detects the engine coolant temperature and relays signals to the ECM. It employs a thermistor which is sensitive to changes in temperature. The electric resistance of a thermistor decreases in response to temperature rise. The ECM judges engine coolant temperature by the sensor output voltage and provides optimum fuel enrichment when the engine is cold.



T8EC010A

CIRCUIT DIAGRAM



IFTD711A


USING HI-SCAN

Check item	Data display	Check conditions	Engine state	Test specification
Engine coolant temperature sensor	Sensor temperature	Ignition switch : ON or engine running	When -20°C (-40°F)	-20°C
			When 0°C (32°F)	0°C
			When 20°C (68°F)	20°C
			When 40°C (104°F)	40°C
			When 80°C (176°F)	80°C


USING VOLTMETER

Check item	Engine state	Test specification
Engine coolant temperature sensor output voltage	When 0°C	4.05V
	When 20°C	3.44V
	When 40°C	2.72V
	When 80°C	1.25V

HARNESS INSPECTION PROCEDURES

<p>1</p>  <p>Harness side connector</p>	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage : 4.8 - 5.2V 	<p>OK → 2</p> <p>NG → Repair the harness.</p>
---	---	--


IFTC711B

<p>2</p>  <p>Harness side connector</p>	<p>Check for continuity of the ground circuit.</p> <ul style="list-style-type: none"> o Connector : Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
---	---	---

IFTC711C

SENSOR INSPECTION

1. Remove the engine coolant temperature sensor from the intake manifold.
2. With the temperature sensing portion of the engine coolant temperature sensor immersed in hot water, check resistance.



EFDA711C

Temperature °C (°F)	Output voltage (kΩ)
-30 (-22)	22.22 - 31.78
-10 (14)	8.16 - 10.74
0 (32)	5.18 - 6.60
20 (68)	2.27 - 2.73
40 (104)	1.059 - 1.281
60 (140)	0.538 - 0.650
80 (176)	0.298 - 0.322
90 (194)	0.219 - 0.243

3. If the resistance deviates from the standard value greatly, replace the sensor.

INSTALLATION

1. Apply sealant LOCTITE 962T or equivalent to threaded portion.
2. Install engine coolant temperature sensor and tighten it to specified torque.

Tightening torque

Engine coolant temperature sensor :

15-20Nm (150-200 kg-cm, 11-15 lb-ft)


3. Connect the harness connector securely.

TROUBLESHOOTING HINTS

1. If the fast idle speed is not enough or the engine gives off dark smoke during the engine warm-up operation, the engine coolant temperature sensor might be the causes.
2. If the thermostat opening state is abnormal which causes over cooling, the DTC for the engine coolant temperature can be displayed on Hi-SCAN.


THROTTLE POSITION SENSOR (TPS) IFTD7130

The TP Sensor is a rotating type variable resistor that rotates with the throttle body's throttle shaft to sense the throttle valve angle. As the throttle shaft rotates, the throttle angle of the TP Sensor changes and the ECM detects the throttle valve opening based on the TPS output voltage.



T7FL010D

CIRCUIT DIAGRAM



IFTD713A

TROUBLESHOOTING HINTS


1. The TPS signal is important for the control of an automatic transaxles. Shift shock and other trouble may occur if the sensor is faulty.

2. If the idle condition or acceleration is abnormal, check the TPS connector. (When the TPS connector is not connected properly, the current data on HI-SCAN can show that the idle state remains off, although the accelerator pedal is released. This results in the improper idle or acceleration.)
3. Input voltage from throttle position sensor is below 0.1V or above 4.7V when ignition switch is turned on.


USING VOLTMETER

Check item	Check condition	Test specification
Throttle position sensor output voltage	At idle rpm	0.1 - 0.875V
	Wide open throttle	4.25 - 4.8V


HARNESS INSPECTION PROCEDURES

1	 <p>Harness side connector</p>	<p>Measure the power supply voltage of the throttle position sensor.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage : 4.8 - 5.2V 	<p>OK → 2</p> <p>NG → Repair the harness.</p>
----------	---	---	--

IFTC713B

2	 <p>Harness side connector</p>	<p>Check for continuity of the ground circuit.</p> <ul style="list-style-type: none"> o Connector : Disconnected 	<p>OK → 3</p> <p>NG → Repair the harness.</p>
----------	---	---	--

IFTC713C


3	 <p>ECM harness side connector</p> <p>Harness side connector</p>	<p>Check for an open-circuit, or a short-circuit to ground between the engine control module and the throttle position sensor.</p> <ul style="list-style-type: none"> o Throttle position sensor connector: Disconnected o Engine control module connector: Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
----------	---	--	---

IFTC713D

SENSOR INSPECTION


1. Disconnect the throttle position sensor connector.
2. Measure the resistance between terminals 1 (sensor ground) and terminal 4 (sensor power).

Standard value : 0.7 - 3.0 k Ω



IFTC713E

3. Connect an analog ohmmeter between terminals 1 (sensor ground) and terminal 3 (sensor output).



IFTC713F

4. Operate the throttle valve slowly from the idle position to the fuel open position, and check that the resistance changes smoothly in proportion with the throttle valve opening angle.
5. If the resistance is out of specification, or fails to change smoothly, replace the throttle position sensor.


Tightening torque

Throttle position sensor :

1.5-2.5Nm (15-25kg·cm, 1.1-1.8 lb·ft)

**CAMSHAFT POSITION SENSOR
(CMP SENSOR)** IFTD7150

The camshaft position sensor (CMP Sensor) senses the TDC point of No.1 cylinder on its compression stroke. Its signal is fed to the ECM to be used to determine the sequence of fuel injection.




IFTD715A


USING VOLTMETER

Check item	Check condition	Test specification
Camshaft position sensor output voltage	At idle rpm	0 - 5V
	3000 rpm	0 - 5V


HARNESS INSPECTION PROCEDURES

1	 <p>Harness side connector</p>	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage (V) : Battery voltage 	<p>OK → 2</p> <p>NG → Repair the harness</p>
----------	---	--	---

IFTC715B

2	 <p>Harness side connector</p>	<p>Check for continuity of the ground circuit.</p> <ul style="list-style-type: none"> o Connector : Disconnected 	<p>OK → 3</p> <p>NG → Repair the harness</p>
----------	---	---	---

IFTC715C

3	 <p>ECM harness side connector</p> <p>Harness side connector</p> <p>ECM</p>	<p>Check for an open-circuit, or a short-circuit to ground between the engine control module and the camshaft position sensor.</p> <ul style="list-style-type: none"> o Camshaft position sensor connector: Disconnected o Engine control module connector: Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
----------	--	--	---


IFTC715D

CRANKSHAFT POSITION SENSOR (CKP SENSOR) IFTD7170

this crankshaft position sensor is relayed to the ECM to indicate engine RPM and the position of the crankshaft.

The crankshaft position sensor, consisted of a magnet and coil, is located next to flywheel. The voltage signal from

CIRCUIT DIAGRAM



IFTD717A


HARNESS INSPECTION PROCEDURE

<p>1</p> <p>Harness side connector</p>	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage (V) : Battery voltage 	<p>OK → 2</p> <p>NG → Repair the harness</p>
---	--	---

EFTC717B


<p>2</p> <p>Harness side connector</p>	<p>Check for continuity of the ground circuit.</p> <ul style="list-style-type: none"> o Connector : Disconnected 	<p>OK → 3</p> <p>NG → Repair the harness</p>
---	---	---

EFTC717C

<p>3</p>  <p>ECM harness side connector</p> <p>Harness side connector</p>	<p>Check for an open-circuit, or a short-circuit to ground between the engine control module and the crankshaft position sensor.</p> <ul style="list-style-type: none"> o Crankshaft position sensor connector: Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
---	---	---


OXYGEN SENSOR IFTD7190

The heated oxygen sensor senses the oxygen concentration in the exhaust gas, then converts it into a voltage and then sends this to the ECM. The oxygen sensor gives an output of about 800mV when the air fuel ratio is richer than the theoretical ratio and output of about 100mV when the ratio is leaner (high oxygen concentration in exhaust gas.) The ECM controls fuel injection based on this signal so that the air fuel ratio is maintained at the theoretical ratio.



T8EC007A

CIRCUIT DIAGRAM



IFTD719A

TROUBLESHOOTING HINTS

1. If the oxygen sensor is defective, abnormally high emissions may occur.
2. If the oxygen sensor check is normal but the sensor output voltage is out of specification, check for the following items related to the air fuel ratio control system:
 - Faulty injector.

- Air leaks in the intake manifold.
- Faulty MAP sensor, purge valve and engine coolant temperature sensor.
- Wiring connection problem.

USING VOLTMETER/HI-SCAN

Check item	Check condition	Engine condition	Test specification
Oxygen sensor output voltage	Warm-up	When decelerating suddenly from 4,000 rpm	A. 200mV or lower
		When engine is suddenly raced	B. 600-1,000mV


NOTE

If you release the accelerator pedal suddenly after engine running about 4000 rpm, fuel supply will stop for short period and the O₂ sensor service data in the HI-SCAN will display values in the A range.


When you suddenly press on the acclerator pedal down, the O₂ sensor service data in the Hi-SCAN will display voltage in the B range.

When you let the engine idle again, the voltage will fluctuate between ranges A and B. In this case, the O₂ sensor can be determined as good.


HARNESS INSPECTION PROCEDURE (EXCEPT INDIA)

1	 <p>Harness side connector (A)</p>	<p>Measure the power supply voltage of the heated oxygen sensor.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage (V) : Battery voltage 	<p>OK → 2</p> <p>NG → Repair the harness.</p>
----------	---	--	--


EFKD208B

2	 <p>ECM harness side connector</p> <p>Harness side connector (A)</p>	<p>Check for an open-circuit, or a short-circuit to ground between the engine control module and the heated oxygen sensor.</p> <ul style="list-style-type: none"> o Heated oxygen sensor connector: Disconnected o ECM connector : Disconnected 	<p>OK → 3</p> <p>NG → Repair the harness.</p>
----------	--	---	--

EFKD208C


3	 <p>Harness side connector (A)</p>	<p>Check for continuity to ground circuit.</p> <ul style="list-style-type: none"> o Connector : Disconnected 	<p>OK → 4</p> <p>NG → Repair the harness.</p>
----------	---	---	--

EFKD208D

4	 <p>Harness side connector (A)</p>	<p>Check for an open circuit, or a short circuit to ground between the ECM and oxygen sensor.</p> <ul style="list-style-type: none"> o Oxygen sensor connector : Disconnected o ECM connector : Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
----------	---	--	---

EFKD208E

HARNESS INSPECTION PROCEDURE (INDIA)

 <p>Harness side connector</p>	<p>Measure the power supply voltage of the heated oxygen sensor.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage (V) : Battery voltage 	<p>OK → END!</p> <p>NG → Repair the harness</p>
---	--	--

IFTC719B

SENSOR INSPECTION

 **NOTE**

1. Before checking, warm up the engine until the engine coolant temperature reaches 80 to 95°C (176 to 205°F).
2. Use an accurate digital voltmeter.

Replace the oxygen sensor if there is a malfunction.

Tightening torque


Heated oxygen sensor :

50-60 Nm (500-600 kg·cm, 37-44 lb·ft)

INJECTORS EFTD7210

The injectors inject fuel according to a signals from the ECM. The volume of fuel injected by the injector is determined by the time for which the solenoid valve is energized.

CIRCUIT DIAGRAM



IFTD721A

TROUBLESHOOTING HINTS

1. If the engine is difficult to start when it is hot, check low for fuel pressure and injector leaks.
2. If the injector does not operate when the engine is cranked, then check the following:
 - Faulty power supply circuit to the ECM or faulty ground circuit.
 - Faulty MFI control relay.
 - Faulty crankshaft position sensor or camshaft position sensor.
3. If engine idle remains unchanged when fuel injection to the cylinders are is cut one after another, check for the following items about such cylinder:
 - Injector and harness.
 - Spark plug and high tension cable.
 - Compression pressure.

4. If the injection system is OK but the injector drive time is out of specification, check for the following items:
 - Poor combustion in the cylinder (faulty spark plug, ignition coil, compression pressure, etc.)
5. The MIL is on or the DTC is displayed on the HI-SCAN under the following condition.
 - When the injector itself is faulty


USING HI-SCAN

Check item	Data display	Check conditions	Engine state	Test specification
Injector	Drive time	<ul style="list-style-type: none"> • Engine coolant temperature: 80 to 95°C (176 to 205°F) • Lamps, electric cooling fan, accessory units: ALL OFF • Transaxle : Neutral (P range for vehicle with A/T) • Steering wheel : Neutral 	Idle rpm	1.5 - 4.5 ms
			2000 rpm	
			3000 rpm	
			Racing	Increasing

Check item	Check condition	HI-SCAN display	Type
Injector • Actuator test	IG. S/W ON (Do not start)	01. No.1 Injector	Activate
		02. No.2 Injector	Activate
		03. No.3 Injector	Activate
		04. No.4 Injector	Activate

HARNES INSPECTION PROCEDURES

1



Harness side connector

Measure the power supply voltage of the injector.


- o Connector : Disconnected
- o Ignition switch : ON
- o Voltage (V) : Battery voltage

OK → **2**

NG → Repair the harness.

EFTC721B

2



Harness side connector

ECM harness side connector

Check for an open-circuit, or a short-circuit to ground between the engine control module and the injector.

- o ECM connector : Disconnected
- o Injector connector : Disconnected

OK → **END!**

NG → Repair the harness.


IFTC721C

INJECTOR INSPECTION

OPERATION CHECK

Using a HI-SCAN:

- Activate the fuel injectors in sequence.
- Check the operating time of the injectors.



EFDA721C


OPERATION SOUND CHECK

1. Using a stethoscope, check the injectors for a clicking sound at idle. Check that the sound is produced at shorter intervals as the engine speed increases.

 **NOTE**

Ensure that the sound from an adjacent injector is not being transmitted along the delivery pipe to an inoperative injector.


2. If a stethoscope is not available, check the injector operation with your finger.
If no vibrations are felt, check the wiring connector, injector, or injection signal from ECM.



EFDA721D

Resistance Measurement Between Terminals

1. Disconnect the connector at the injector and measure the resistance between the two terminals.



EFDA721E


Standard value : $15.9 \pm 0.35 \Omega$ [at 20°C (68°F)]

2. Re-connect the connector to the injector.

IDLE SPEED CONTROL ACTUATOR (ISC ACTUATOR)


IFTD7230

The idle speed actuator is a double coil type driven by separate driver stages in the ECM. Depending on the pulse duty factor, the equilibrium of the magnetic forces of the two coils will result in different angles of the motor. A bypass hose line is positioned, in parallel to the throttle valve where the idle speed actuator is inserted.



IFTC723G

CIRCUIT DIAGRAM



IFTD723A


TROUBLESHOOTING HINTS

Open or short circuit is observed in idle air control system when ignition switch is turned on.


USING HI-SCAN

Check item	Check condition	Engine condition	Test specification
Idle speed control actuator • Actuator test	IGN S/W ON (Do not start)	ISCV	Activate

HARNESS INSPECTION PROCEDURE

<p>1</p>  <p>Harness side connector</p>	<p>Measure the power supply voltage of the injector.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage (V) : Battery voltage 	<p>OK → 2</p> <p>NG → Repair the harness.</p>
---	--	--

EFTC723B

<p>2</p>  <p>Harness side connector</p>	<p>ECM harness side connector</p> <p>Check for an open-circuit, or a short-circuit to ground between the ECM and the idle speed control actuator.</p> <ul style="list-style-type: none"> o ECM connector : Disconnected o Idle speed actuator connector: Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
---	---	---

IFTC723C

ACTUATOR INSPECTION

RESISTANCE MEASUREMENT BETWEEN TERMINALS

1. Disconnect the connector at the idle speed control actuator.
2. Measure the resistance between terminals.

Standard value

Terminal 1 and 2 : 12 - 18Ω


Terminal 2 and 3 : 12 - 16Ω [at 20°C (68°F)]

3. Connect the connector to the idle speed control actuator.

VEHICLE SPEED SENSOR IFTD7250

The vehicle speed sensor is a reed switch that is built into the speedometer. The sensor converts the transaxle gear revolutions into a pulse signal which is sent to the ECM.

CIRCUIT DIAGRAM




IFTD725A

TROUBLESHOOTING HINTS

If there is an open or short circuit in the vehicle speed sensor signal circuit, the engine may stall when the vehicle decelerates to a stop.

HARNES INSPECTION PROCEDURES




IFTC725B

AIR CONDITIONING SWITCH AND RELAY


IFTD7350

The air conditioning switch applied battery voltage to the ECM when the air conditioning switch is turned on. When the air conditioning ON signal is input, the ECM drives the ISC Actuator and turns ON the ignition power transistor. Then, the air conditioning power relay coil is energized to turn on the relay switch, which activates the compressor magnetic clutch.



EFDA735A

CIRCUIT DIAGRAM




IFTD735A

USING HI-SCAN

Check item	Data Display	Check condition	Air conditioning switch	Normal indicator
Air conditioning switch	Switch state (ON/OFF)	Engine: Idling (air compressor is running when air conditioning switch is ON)	OFF	OFF
			ON	ON
Air conditioning compressor	Air conditioning compressor	Engine: Idling after warm-up	OFF	OFF (compressor clutch non-activation)
			ON	ON

HARNESS INSPECTION PROCEDURE

<p>ECM harness side connector</p> 	<p>Measure the power supply voltage of the air condition circuit.</p> <ul style="list-style-type: none"> o Air condition switch : ON o Engine control unit connector: Disconnected o Ignition switch : ON o Voltage : Battery voltage 	<p>OK → END!</p> <p>NG → Check the air conditioning circuit</p>
--	---	--


IFTC735B

AIR CONDITIONING INSPECTION

Refer to GROUP-HA service adjustment procedures.


**EVAPORATIVE EMISSION CANISTER
PURGE SOLENOID VALVE** IFTD7370

The evaporative emission canister purge solenoid valve is a duty control type, which controls the flow of purge air from the evaporative emission canister.



EEDA204A

CIRCUIT DIAGRAM




IFTD737A


USING HI-SCAN

Check item	Check condition	HI-SCAN display	Type
Evaporative emission canister purge solenoid valve • Actuator test	Start the engine	PURGE VALVE	Activate

HARNESS INSPECTION PROCEDURE

<p>1</p>  <p>Harness side connector</p>	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage : Battery voltage 	<p>OK → 2</p> <p>NG → Repair the harness.</p>
---	--	--

IFTC737B

<p>2</p>  <p>Harness side connector</p> <p>ECM harness side connector</p>	<p>Check for an open-circuit, or a short-circuit to ground between the evaporative emission canister purge solenoid valve and the engine control module.</p> <ul style="list-style-type: none"> o Engine control module connector : Disconnected o Evaporative emission canister purge solenoid valve connector : Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
---	--	---

IFTC737C


ACTUATOR INSPECTION

Refer to GROUP EC-Evaporative Emission System.

MFI CONTROL RELAY IFTD7390

When the ignition switch is on, battery power is supplied to the ECM, the injectors, the MAP sensor, etc. While the ignition switch is turned on, current flows from the ignition switch through the current relay coil to ground.

CIRCUIT DIAGRAM



IFTD739A

HARNESS INSPECTION PROCEDURES


<p>1</p> <p>Harness side connector</p>	<p>Measure the power supply voltage of the MFI control relay.</p> <ul style="list-style-type: none"> o MFI control relay connector : Disconnected o Voltage (V) : Battery voltage 	<p>OK → 2</p> <p>NG → Repair the harness.</p>
---	---	--

IFTD739B


IGNITION COIL IFTD7410

When the ignition power transistor is turned ON by a signal from the ECM, the ECM sends a signal to the ignition coil, then the primary current is shut off and a high voltage is induced in the secondary coil.


CIRCUIT DIAGRAM




HARNESS INSPECTION PROCEDURE

1	 <p>Harness side connector</p>	<p>Measure the power supply voltage of the ignition coil.</p> <ul style="list-style-type: none"> o Connector : Disconnected o Ignition switch : ON o Voltage(V) : Battery voltage 	<p>OK → 2</p> <p>NG → Repair the harness</p>
----------	---	--	---

IFTC741B

2	 <p>ECM harness side connector</p> <p>Harness side connector</p>	<p>Check for an open-circuit, or a short-circuit to ground between the ignition coil and the engine control module.</p> <ul style="list-style-type: none"> o Engine control module connector : Disconnected o Power transistor connector : Disconnected 	<p>OK → 3</p> <p>NG → Repair the harness.</p>
----------	---	---	--

IFTC741C


3	 <p>ECM harness side connector</p> <p>Harness side connector</p>	<p>Check for an open-circuit, or a short-circuit to ground between the ignition coil and the engine control module.</p> <ul style="list-style-type: none"> o Engine control module connector : Disconnected o Power transistor connector : Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
----------	---	---	---

IFTD741D

ACCELERATION SENSOR IFTD7450

The acceleration sensor is used to sense rough road conditions. The sensor's signal is used by the Engine Control Module (ECM) to prevent wrongful misfire detection.

CIRCUIT DIAGRAM



IFTD745A


USING VOLTMETER

Check item	Check condition	Test specification
Acceleration sensor output voltage.	While idling	2.3 - 2.7V
	While driving	0.5 - 4.5V


HARNESS INSPECTION PROCEDURE

<p>1</p> <p>Harness side connector</p>	<p>Check for continuity of the ground circuit.</p> <ul style="list-style-type: none"> o Connector : Disconnected 	<p>OK → 2</p> <p>NG → Repair the harness</p>
---	---	---

EFTC745B

<p>2</p>  <p>Harness side connector</p>	<p>Measure the power supply voltage</p> <ul style="list-style-type: none"> o Acceleration sensor connector : Disconnected o Voltage : 5V 	<p>OK → 3</p> <p>NG → Repair the harness</p>
---	--	---

EFTC745C


<p>3</p>  <p>Harness side connector</p>	<p>Check for an open-circuit, or a short-circuit to ground between the engine module and the acceleration sensor.</p> <ul style="list-style-type: none"> o Acceleration sensor connector : Disconnected o Engine control module connector : Disconnected 	<p>OK → END!</p> <p>NG → Repair the harness.</p>
---	--	---

EFTC745D

FUEL DELIVERY SYSTEM

THROTTLE BODY

COMPONENTS EFTC8090



T7FL015A

REMOVAL EFTC8110


CAUTION

The throttle valve must not be removed.

Remove the throttle position sensor.

NOTE

Except when necessary for replacement, the throttle position sensor must not be removed.



T7FL010D


INSPECTION

EFDA8130

1. Check the throttle body for cracks.
2. Check for restriction in the vacuum port or passage.
3. Check for interference when moving the accelerator cable.

 **CAUTION**


- *Throttle valve set screw was adjusted in the production line with the air volume ($0.516 \pm 5\%$ g/sec) during idling. So please **DO NOT ADJUST IT** voluntarily.*
- *When the idle rpm is out of specification, check the relevant sensors and their input or output value first.*
- *The throttle body does not need to be cleaned because carbon in throttle body does not affect the system's operation at all.*



EFDA813A

ACCELERATOR PEDAL


COMPONENTS EFTC8310




EFDA831A

REMOVAL IFTC8330

1. Remove the bushing and inner cable of the accelerator arm side.
2. After disconnecting the accelerator switch connector (At only), loosen the bolts of the accelerator arm bracket and remove.



EFDA833A




T7FL024A

INSPECTION EFDA8350

1. Check the inner and outer cable for damage.
2. Check the cable for smooth movement.
3. Check the accelerator arm for deformation.
4. Check the return spring for deterioration.
5. Check the connection of the bushing to end metal fitting.
6. Check that the accelerator switch operates properly.


3. Securely install the resin bushing of the accelerator cable on the end of the accelerator arm.
4. Apply multipurpose grease around the cable end.



INSTALLATION EFTC8370

EFDA837C

1. When installing the return spring and accelerator arm, apply multi-purpose grease around each moving point of the accelerator arm.




EFDA837A

2. Apply sealant to the bolt mounting hole, and tighten the accelerator arm bracket.

Tightening torque

Accelerator arm bracket bolts :


8-12Nm (80-120 kg·cm, 5.8-7.2 lb·ft)



T7FL024A

FUEL INJECTOR

COMPONENTS IFTC8010



REMOVAL EFTC8030

1. Release residual pressure from the fuel line to prevent fuel from spilling.


CAUTION

Cover the hose connection with rags to prevent splashing of fuel that could be caused by residual pressure in the fuel line.

2. Remove the delivery pipe with the fuel injectors.

CAUTION

- *Be careful not to drop any injectors when removing the delivery pipe.*
- *Be aware that fuel may flow out when removing the injector.*




T7FL010F

INSPECTION EFDA8050

1. Measure the resistance of the injectors between the terminals using an ohmmeter.

Resistance : $15.9 \pm 0.35\Omega$ [at 20°C (68°F)]


2. If the resistance is not within specifications, replace the injector.



EFDA805A

INSTALLATION EFDA8070

1. Install a new grommet and O-ring to the injector.
2. Apply a coating of solvent, spindle oil or gasoline to the O-ring of the injector.




EFDA807A

3. While turning the injector to the left and right, fit it on to the delivery pipe.
4. Be sure the injector turns smoothly.

NOTE


If it does not turn smoothly, the O-ring may be jammed: Remove the injector and re-insert it into the delivery pipe and recheck.



EFDA807B

FUEL LINE AND VAPOR LINE

COMPONENTS EFTC8220



REMOVAL EFTC8230

1. Remove the upper eye bolt while holding the fuel filter nut securely and remove the high pressure fuel hose.

 **CAUTION**

- ***Be sure to reduce the fuel pressure before disconnecting the fuel line and hose, otherwise fuel will spill out.***
- ***Cover the hose connection with a shop towel to prevent splashing of fuel that could be caused by residual pressure in the fuel line.***




T7FL003A

2. Remove the lower eye bolt while holding the fuel filter nut assembly.
3. Remove the fuel filter mounting bolts, then remove the fuel filter from the bracket.
4. Remove the fuel return hose and line.
5. Remove the fuel vapor hose and line.

FUEL TANK


COMPONENTS EFTC8150



T7FL017A

REMOVAL EFTC8170

1. Press the two taps under the rear seat and raise the seat, then detach the inspection panel of the fuel pump.




EFDA013A

- To reduce the internal pressure of the fuel lines and hoses, first start the engine with the fuel pump disconnected and wait until it stops by itself.


 **NOTE**

Be sure to reduce the fuel pressure before disconnecting the fuel main pipe and hose otherwise fuel will spill out.



T7FL020A

- Disconnect the battery cable from the negative terminal of the battery.



EFDA817B


- Disconnect the high pressure hose from the fuel filter output side, and disconnect the tap for static electricity.

 **CAUTION**

Cover the hose connection with a shop towel to prevent splashing of fuel that could be caused by residual pressure in the fuel line.


- Lift up the vehicle.

- Detach the fuel filler hose and leveling hose.
- Support the fuel tank with a jack.



T7FL019A

- Remove the fuel tank bands.
- Remove the fuel tank.




T7FL021A

INSPECTION EFDA8190


- Check the hoses and the pipes for cracks or damage.
- Check the fuel tank cap for proper operation.
- Check the fuel tank for deformation, corrosion or cracking.
- Check the inside of the fuel tank for dirt or foreign material.
- Check the in-tank fuel filter for damage or restriction.
- Test the two-way valve for proper operation.

- To check the two-way valve, lightly blow into the inlet and outlet. If air passes through after slight resistance, then the valve is good.



EFDA819A

- Connect the vapor hose. When attaching the vapor hose to the line, be sure that the hose is attached as shown in the illustration.




EFDA821B

INSTALLATION

IFTC8210


- Confirm that the pad is fully bonded to the fuel tank, and install the fuel tank by tightening the self-locking nuts.



T7FL021A

- Connect the high pressure hose to the fuel pump. Be careful that the fuel hose does not twist.
- Connect the electrical fuel pump connector.

- Connect the leveling hose to the tank and at the filler neck by approximately 40mm (1.6 in.).
- When connecting the filler hose, the end with the shorter straight pipe should be connected to the tank side.



EFDA821A

TROUBLESHOOTING FOR DTC

DIAGNOSTIC ITEM IFTD5020

DTC	Diagnostic item
P0106	Manifold Absolute Pressure (MAP) Sensor Circuit Rationality
P0107	Manifold Absolute Pressure (MAP) Sensor Circuit Low Input
P0108	Manifold Absolute Pressure (MAP) Sensor Circuit High Input


DESCRIPTION

The MAP sensor is essentially a strain gauge used to measure the pressure in the surge tank. Inside the sensor is a metal diaphragm with a small wire attached. The diaphragm flexes according to changes in pressure. When the diaphragm flexes, the wire attached to it stretches, changing the resistance of the wire. The Engine control Module (ECM) applies five volts to the MAP sensor and measures the voltage drop across the sensor. Sensor output is in volts and as pressure decreases, the voltage drop across the sensor increases. Since the MAP sensor is used as an air flow sensor, the sensor signal is an important input. The ECM uses the information to determine fuel amount and ignition timing.


FAILURE CONDITIONS

The MAP sensor outputs a voltage which corresponds to the pressure in the surge tank. The ECM checks whether this voltage is within a specified range. The ECM will set P0107 if the MAP sensor output voltage has continued to be 4.5V or higher — corresponding to a surge tank pressure of 114kPa (17psi) or higher — for 4 sec. and P0108 if the MAP sensor output voltage has continued to be 1.95V or lower — corresponding to a surge tank pressure of 50kPa (7.4psi) or lower — for 4 sec.

CIRCUIT DIAGRAM



TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE



- Turn ignition off.
 - Disconnect MAP & IAT sensor.
 - Measure resistance between ground and MAP & IAT sensor pin No.4.
- Resistance should be approximately 1 ohm or less, is it?

YES

Replace MAP sensor. Clear code and verify MAP sensor is within normal parameters.

NO

Repair open circuit in wire between MAP sensor harness connector terminal 4 and ECM. Clear code and verify MAP sensor is within normal parameters.

IFTD5060

DTC	Diagnostic item
P0112 P0113	Intake Air Temperature Low Input In take Air Temperature High Input


DESCRIPTION

The Intake air temperature (IAT) sensor is built in to the MAP sensor. The IAT sensor is a variable resistor whose resistance changes as the temperature of the air flowing through the air intake changes. The Engine Control Module (ECM) uses the IAT sensor input to adjust fuel injector pulse width. When the temperature sensed is cold, the ECM enriches fuel mixture by increasing injector pulse width; as the air warms, the injector pulse width time is shortened.

FAILURE CONDITIONS

The ECM will set P0112 and the Malfunction Indicator Lamp(MIL) will turn ON if the IAT sensor indicates a temperature lower than -49°F (-45°C) for 0.2 seconds during two driving cycles. This check is made after the engine has run for 4 minutes and 10 seconds and then idles for 30 seconds (with no fuel cut-off during a coast-down). This code indicates a lower than expected temperature is being read by the IAT sensor or ECM after the engine has been warmed up.

CIRCUIT DIAGRAM



IFTD707A

TEST PROCEDURE

- Turn ignition switch on.
- Connect Scan tool to data link connector.
- Verify DTC P0112 or P0113 is set.

- Engine at ambient temperature (overnight cool down in shop recommended).
- Measure shop air temperature.
- Turn ignition on.
- Using scan tool, observe intake air temperature (IAT) sensor reading. Scanned temperature should be very close to shop air temperature, is it?

No, scanned temperature is below shop air temperature.

Yes, scanned temperature is very close to measured shop air temperature.

- Turn ignition off.
- Disconnect Intake IAT sensor.
- Turn ignition on.

Measure voltage between ground and IAT sensor harness connector terminal 3. Voltage measured should be 4.5 to 5.0 volts, is it?

No problem found at this time. Fault is intermittent or was repaired and Engine Control Module (ECM) memory was not cleared. Clear code and verify IAT sensor is within normal parameters.

Yes, 4.5 to 5.0 volts is present.

No, 0 volts is present.



CONTINUED ON NEXT PAGE (for P0112)



CONTINUED ON NEXT PAGE

(for P0112) CONTINUED
FROM PREVIOUS PAGE



(for P0112) CONTINUED
FROM PREVIOUS PAGE



• IAT sensor disconnected.
• Turn Ignition off.
• Disconnect ECM connector.
• Measure resistance between IAT sensor harness connector terminal 3 and ECM harness connector terminal 32.
Resistance should be approximately 1 ohm or less, is it?

YES

NO

• IAT sensor disconnected.
• ECM disconnected.
• Measure resistance between IAT sensor harness connector terminal 3 and ECM harness connector terminal 32.
Resistance should be approximately 1 ohm or less, is it?

Repair open in wire between IAT sensor harness connector terminal 3 and ECM. Clear code and verify IAT sensor is within normal parameters.

YES

NO

Verify ECM connector is secure.
If OK, replace IAT sensor with known good component. Clear code and verify IAT sensor is within normal parameters. If problem persists, replace ECM.

Repair open circuit in wire between IAT sensor harness connector terminal 1 and ECM. Clear code and verify IAT sensor is within normal parameters.

IFTD5110

DTC	Diagnostic item
P0116	Engine Coolant Temperature Circuit Range / Performance
P0117	Engine Coolant Temperature Circuit Low Input
P0118	Engine Coolant Temperature Circuit High Input

DESCRIPTION

The Engine Coolant Temperature (ECT) sensor is located in the coolant passage of the cylinder head. The ECT sensor is a variable resistor whose resistance changes as the temperature of the engine coolant flowing past the sensor changes. When coolant temperature is low, sensor resistance is high; when coolant temperature is high, sensor resistance is low.

The Engine Control Module (ECM) checks ECT sensor voltage and uses the information to adjust fuel injector pulse width and ignition timing. When the temperature sensed is very cold, the ECM enriches the fuel mixture and advances ignition timing. As coolant temperature rises, the ECM reduces the amount of enrichment and timing advance.

FAILURE CONDITIONS

The ECM will set P0116 and the Malfunction Indicator Lamp(MIL) (If installed) will turn on if the ECT sensor's actual performance curve falls more than 68°F (20°C) below the ECM's model curve (based on fuel delivery, ambient air temperature and engine running time) for 0.2 seconds

during two driving cycles. This code indicates uncharacteristic engine temperature performance being read by the ECT sensor or ECM.


The ECM will set P0117 and the Malfunction Indicator Lamp(MIL) (If installed) will turn on if the ECT sensor reports a temperature below -49°F (-45°C) for 0.2 seconds during two driving cycles. The ECM will set P0118 and the Malfunction Indicator Lamp(MIL) (If installed) will turn on if the ECT sensor reports a temperature above 284°F (140°C) for 0.2 seconds during two driving cycles.

NOTE


The ECT sensor resistance varies with temperature as follows:


- 5900 ohms @ 32°F (0°C).
- 2500 ohms @ 68°F (20°C).
- 300 ohms @ 176°F (80°C).

CIRCUIT DIAGRAM



TEST PROCEDURE





CONTINUED FROM
PREVIOUS PAGE



• Turn ignition off.
• ECT sensor disconnected.
• Disconnect ECM connector.
• Ground ECT sensor harness connector terminal 3.
• Measure resistance between ground and ECM harness connector terminal 35.
Resistance should be approximately 1 ohm or less, is it?

YES

NO

• ECT sensor disconnected.
• ECM disconnected.
• Measure resistance between connector pin No.1 and ECM harness connector terminal 39.
Resistance should be approximately 1 ohm or less, is it?


Repair open in wire between ECT sensor harness connector terminal 3 and ECM harness connector terminal 35. Clear code and verify ECT sensor is within normal parameters.

YES

NO

Verify ECM connector is secure. If OK, replace ECT with known good component. Clear code and verify ECT sensor is within normal parameters. If problem persists, replace ECM.

Repair open in wire between ECT sensor harness connector terminal 1 for and ECM harness connector terminal 36. Clear code and verify ECT sensor is within normal parameters.



IFTD5160

DTC	Diagnostic item
P0121	TPS Circuit Range / Performance Problem
P0122	TPS Circuit Low Input
P0123	TPS Circuit High Input

DESCRIPTION

The Throttle Position sensor mounts on the side of the throttle body and is connected to the throttle valve shaft. The TPS is a variable resistor (potentiometer) whose resistance changes according to throttle valve shaft position. During acceleration, the TPS resistance decreases; during deceleration, the TPS resistance increases.

The Engine Control Module (ECM) applies a reference voltage to the TPS and then measures the voltage that is present on the TPS signal circuit. The ECM uses the TPS signal to adjust timing and injector pulse width. The TPS signal along with the MAP sensor signal is used by the ECM to calculate engine load.

FAILURE CONDITIONS

The ECM will set P0121 and the Malfunction Indicator Lamp(MIL) will turn on if the engine load indicated by the Throttle Position (TP) sensor and the MAP sensor are different. This code indicates that the throttle position and air

flow readings by the TP and MAF sensor, or ECM, do not result in the expected engine load value.


The ECM will set P0122 and the Malfunction Indicator Lamp(MIL) will turn on if the throttle angle is reported as less than 2.1 degrees for more than 0.2 seconds during 2-driving cycles. This code indicates an unusually low throttle position angle being read by the TP sensor or ECM.

The ECM will set P0123 and the Malfunction Indicator Lamp(MIL) will turn on if the throttle angle is reported as greater than 105.4 degrees for 0.2 seconds during 2-driving cycles. This code indicates an unusually high throttle position angle being read by the TP sensor or ECM.

NOTE

The standard resistance value between terminals 4 and 3 of the throttle position sensor is 1600-2500 ohms.

CIRCUIT DIAGRAM



TEST PROCEDURE

- Turn Ignition Switch ON.
- Connect Scan Tool to Data Link Connector.
- Verify DTC P0121, P0122, P0123 is set.

Is DTC P0106, P0107 or P0108 also set?

NO

YES

- Turn ignition on.
- Using scan tool, observe Throttle Position (TP) sensor, RPM and air flow output reading.

TPS	0.5	1.2	1.5	1.9
RPM	idle	2000	3000	4000

Do throttle position sensor, and RPM agree?

Check MAP sensor following test procedure for DTC P0106, P107 or P0108.

No, at given RPM, TP sensor does not agree.

No, at given RPM, MAP does not agree.

YES

- Turn ignition on, engine at idle.
- Wait 15 seconds.
- Using scan tool, observe Throttle Position (TP) sensor's output reading.

Reading should be between 0.5V and 1.5V, is it?

Check MAP sensor following test procedure for DTC P0106, P1017 or P0108.

Problem is intermittent or has been fixed. Clear code and verify TP sensor and MAP sensor are within normal parameters.

No, reading is below 0.5V or between 1.5V and 2V.

No, reading is above 2V.

Yes, reading is between 0.5V and 1.5V.

- Ignition on, engine idle.
- Throttle fully released.
- Attempt to adjust TP sensor output voltage to between 0.5V and 1.5V.

Can TP sensor voltage be adjusted as specified?

- Turn ignition off.
- Disconnect TP sensor.
- Turn ignition on.
- Using voltmeter, measure voltage between TP sensor harness terminal 4 and ground.

Voltage should be approximately 5.0 volts, is it?

Problem is intermittent or was repaired and ECM memory was not cleared. Check terminal connections at ECM and TP sensor. Clear code and verify TP sensor is within normal parameters.

YES

No, voltage is 0 volts.

No, voltage is below 5 volts.


Replace TP sensor. Clear code and verify TP sensor is within normal parameters.

Repair short to ground in wire between TP sensor harness terminal 4 and ECM. Clear code and verify TP sensor is within normal parameters.

Repair short to voltage in wire between TP sensor harness terminal 4 and ECM. Clear code and verify TP sensor is within normal parameters.

A
CONTINUED ON NEXT PAGE

CONTINUED FROM PREVIOUS PAGE



CONTINUED ON NEXT PAGE

CONTINUED FROM
PREVIOUS PAGE

B

NO

YES

- Ignition on, engine off.
- TP sensor disconnected.
- Fused jumper in place.
- With ECM connected, measure voltage (backprobe) between ground and ECM connector terminal 32. 5 volts should be present, is it?

Replace TP sensor.
Clear code and verify TP sensor is within normal parameters.

YES

NO

Verify ECM connector is secure.
Replace ECM if OK. Clear code and verify TP sensor is within normal parameters.

Repair open circuit or short to ground wire between TP sensor harness connector terminal 4 and ECM harness connector terminal 32.
Clear code and verify TP sensor is within normal parameters.

IFTD5210

DTC	Diagnostic item
P0130	Oxygen Sensor Circuit Malfunction (Bank1, Sensor1)

DESCRIPTION

The Engine Control Module (ECM) uses oxygen sensor signals to maintain the air fuel mixture at the ratio resulting in optimum fuel economy and reduced emissions. The amount of oxygen in the exhaust gases indicates, to the oxygen sensor, whether the air fuel mixture being supplied to the engine cylinders is rich or lean.


A normal oxygen sensor signal will constantly fluctuate above and below 500 mV, with the front oxygen sensor signal frequency of at least 5Hz at 2500 RPM.

FAILURE CONDITIONS

(FOR P0130)

After the engine runs, the ECM checks the oxygen sensor once per driving cycle for 5 sec. If during two driving cycles the oxygen sensor's output is not between 0 millivolts and +380 millivolts the ECM will set a code. This code indicates uncharacteristic operation of the front oxygen sensor being read by the ECM.

CIRCUIT DIAGRAM



TEST PROCEDURE

- Turn Ignition Switch on.
- Connect Scan Tool to Data Link Connector.
- Verify DTC P0130 or P0136 is set.

Are other DTCs also set?

NO

YES

- Start engine and warm it to normal operating temperature .
- Vary engine speed and, using scan tool, monitor oxygen sensor voltage.

Voltage should vary between 0 and 900 mV, does it?

Repair conditions that caused other DTCs to set. Refer to DTC test procedures.

No, voltage is constant and the reading is approximately 450 mV.

No, voltage is constant and approximately 5 or 12 volts.

No, 0 volts present.

No, voltage varies but stays below 500 mV (lean).

No, voltage varies but stays above 500 mV (rich).

Yes, voltage varies between 0 and 900 mV.

Repair short to voltage in wiring harness. Clear code and verify oxygen sensor is within normal parameters

B **C**
CONTINUED ON NEXT PAGE

D

- While running the engine, measure voltage (backprobe) between oxygen sensor connector terminals 1 and 2. Does voltage vary above and below 500 mV?

- Disconnect oxygen sensor connector. Does voltage now read approximately 450 mV on scan tool?

NO

YES

For P0130 : Repair short to ground in wire between oxygen sensor harness connector terminal 1 and ECM connector terminal 18. Clear code and verify oxygen sensor is within normal parameters.

Replace oxygen sensor. Clear code and verify oxygen sensor is within normal parameters.

A
CONTINUED ON NEXT PAGE

CONTINUED FROM PREVIOUS PAGE

A

YES

- Ignition off.
- Disconnect front oxygen sensor [for P0130].
- Disconnect ECM connector.
- Ground oxygen sensor harness terminal 1.
- Measure resistance between ground and ECM connector terminal 36 [for P0130].

Resistance measured should be approximately 1 ohm or less, is it?

NO

Replace oxygen sensor. Clear code and verify oxygen sensor is within normal parameters.

YES

Verify ECM connectors are secure. If OK, replace oxygen sensor with known good component. Clear code and verify oxygen sensor is within normal parameters. If problem persists, replace ECM.

NO

Repair open wire or cause of high resistance. Clear code and verify oxygen sensor is within normal parameters.

CONTINUED FROM PREVIOUS PAGE

B

Voltage varies but stays below 500 mV (lean).

- Inspect air inlet downstream of MAP sensor for leaks or damage.
- Inspect exhaust manifold for cracks.

Are any leaks or damage found?

YES

Repair leaks or replace exhaust manifold. Clear code and verify oxygen sensor is within normal parameters.

NO

- Perform fuel pressure test as outlined in shop manual (section FL). Is fuel pressure within specification and no pressure leak down observed?


E

CONTINUED ON NEXT PAGE

CONTINUED FROM PREVIOUS PAGE

C

Voltage varies but stays above 500 mV (rich).



IFTD5260

DTC	Diagnostic item
P0131	Oxygen Sensor Circuit Low Input (Bank1, Sensor1)


DESCRIPTION

Refer to DTC P0130.


FAILURE CONDITIONS

After the Front Oxygen Sensor Heater is on for 3 minutes, the ECM continuously measures the front oxygen sensor's output in 0.5 second intervals. If during two driving cycles the front oxygen sensor's output falls below 50 millivolts for 0.5 seconds, the ECM will set P0131. This code indicates an unusually lean fuel air mixture being read by the front oxygen sensor or ECM.


TEST PROCEDURE



CONTINUED FROM PREVIOUS PAGE



CONTINUED FROM PREVIOUS PAGE



CONTINUED FROM PREVIOUS PAGE

CONTINUED FROM PREVIOUS PAGE

D

E

Voltage varies between 0 and 900 mV.

YES

NO

- Ignition off.
- Disconnect ignition coil connector.
- Measure voltage drop across negative battery cable by connecting voltmeter between negative battery post and cable attachment point on engine while cranking the engine. Voltage drop measured should be less than 0.5 volts, is it?

Follow diagnostic procedures outlined in shop manual. Clear code and verify oxygen sensor is within normal parameters.

YES

NO

- Disconnect negative battery terminal.
- Measure resistance between generator case and engine ground point. Resistance measured should be approximately 1 ohm or less, is it?

Replace negative battery cable. Clear code and verify oxygen sensor is within normal parameters.

YES

NO

- If malfunction Indicator Lamp (MIL) is turning on intermittently and DTC P0131 is set, problem is most likely a poor ground circuit. Clean negative battery terminal and engine ground. Also clean mating surfaces of generator housing and engine block.
- If Malfunction Indicator Lamp (MIL) was on and DTC P0131 is set, replace oxygen sensor.
- Clear code and verify oxygen sensor is within normal parameters.

Clean mating surfaces of generator housing and engine block. Clear code and verify oxygen sensor is within normal parameters.

IFTD5310

DTC	Diagnostic item
P0132	Oxygen Sensor Circuit High Input (Bank1, Sensor1)


DESCRIPTION

Refer to DTC P0130.

FAILURE CONDITIONS**(FOR P0132)**

After the Front Oxygen Sensor Heater has been on for 3 minutes, the ECM continuously measures the front oxygen sensor's output in 0.5 second intervals. If during two driving cycles the front oxygen sensor's output exceeds 1.058 volts for 0.5 seconds, the ECM will set P0132. This code indicates an extremely rich air fuel mixture being read by the front oxygen sensor or ECM.

TEST PROCEDURE



CONTINUED FROM PREVIOUS PAGE



Voltage varies between 0 and 900 mV.

- Ignition off.
- Disconnect ignition coil connector.
- Measure voltage drop across negative battery cable by connecting voltmeter between negative battery post and cable attachment point on engine while cranking the engine. Voltage drop measured should be less than 0.5 volts, is it?

YES

- Disconnect negative battery terminal.
- Measure resistance between generator case and engine ground point. Resistance measured should be approximately 1 ohm or less, is it?

YES

- If DTC P0132 is set intermittently, problem is most likely a poor ground circuit. Clean negative battery terminal and engine ground. Also clean mating surfaces of generator housing and engine block.
- If DTC P0132 is set, replace oxygen sensor.
- Clear code and verify oxygen sensor is within normal parameters.

CONTINUED FROM PREVIOUS PAGE



Voltage varies but stays above 500 mV (rich).

- Perform fuel pressure test as outlined in shop manual. Is fuel pressure within specification and no pressure leak down observed?

YES

NO

Follow diagnostic procedures outlined in shop manual. Clear code and verify oxygen sensor is within normal parameters.

NO

Replace negative battery cable. Clear code and verify oxygen sensor is within normal parameters.

NO

Clean mating surfaces of generator housing and engine block. Clear code and verify oxygen sensor is within normal parameters.

IFTC5360

DTC	Diagnostic item
P0133	Oxygen Sensor Circuit Slow Response (Bank1, Sensor1)
P0134	Oxygen Sensor Circuit Inactive (Bank1, Sensor1)

DESCRIPTION

Refer to DTC P0130 & P0136.

FAILURE CONDITIONS[FOR P0133]**(FOR P0133)**

The ECM will set P0133 if the ECM does not sense the following conditions during two driving cycles:


1. Over a period of 2 minutes, the ECM must sense a fuel compensation factor greater 85% or less than 95%:
2. The ECM must make some correction in the air/fuel ratio when:
 - Engine RPM is between 1600 and 3200 RPM.
 - Engine load range is between 1.35 and 3.4 milliseconds.
 - Catalyst temperature is above 372°C (702°F).
 - System is in closed loop.

This code indicates the engine air fuel ratio is not being adjusted by the front oxygen sensor signal or the ECM as expected to do so, or not adjusted as often as expected to do so once the engine is warmed or under normal engine use.


(FOR P0134)

After the engine runs for 3 minutes, the ECM checks the front oxygen sensor. If during 2 driving cycles the front oxygen sensor's output voltage is not between 400 and 600 millivolts for 5 seconds, the ECM will set a code. This code indicates the front oxygen sensor is not active within the expected range once the engine has been warmed.


TEST PROCEDURE




CONTINUED FROM PREVIOUS PAGE



CONTINUED FROM PREVIOUS PAGE



CONTINUED FROM PREVIOUS PAGE



CONTINUED ON NEXT PAGE

CONTINUED FROM PREVIOUS PAGE



Voltage varies between 100 and 900 mV.

• Ignition off.
 • Disconnect ignition coil connector.
 • Measure voltage drop across negative battery cable by connecting voltmeter between negative battery post and cable attachment point on engine while cranking the engine. Voltage drop measured should be less than 0.5 volts, is it?

YES

• Disconnect negative battery terminal.
 • Measure resistance between generator case and engine ground point. Resistance measured should be approximately 1 ohm or less, is it?

YES

• If DTC P0133 is set intermittently, problem is most likely a poor ground circuit. Clean negative battery terminal and engine ground. Also clean mating surfaces of generator housing and engine block.
 • If DTC P0133 or P0134 is set, replace oxygen sensor.
 • Clear code and verify oxygen sensor is within normal parameters.

CONTINUED FROM PREVIOUS PAGE



YES

NO

Follow diagnostic procedures outlined in shop manual. Clear code and verify oxygen sensor is within normal parameters.

NO

Replace negative battery cable. Clear code and verify oxygen sensor is within normal parameters.

NO

Clean mating surfaces of generator housing and engine block. Clear code and verify oxygen sensor is within normal parameters.

IFTD5410

DTC	Diagnostic item
P0261	Cylinder 1 - Injector Circuit Low
P0262	Cylinder 1 - Injector Circuit High
P0264	Cylinder 2 - Injector Circuit Low
P0265	Cylinder 2 - Injector Circuit High
P0267	Cylinder 3 - Injector Circuit Low
P0268	Cylinder 3 - Injector Circuit High
P0270	Cylinder 4 - Injector Circuit Low
P0271	Cylinder 4 - Injector Circuit High

DESCRIPTION

The fuel injectors are solenoid operated valves. When a fuel injector solenoid is energized (pulsed) the injector needle valve opens, allowing pressurized fuel to pass through the injector and mix with air entering the engine.


The Engine Control Module (ECM) controls injector timing and pulse width. The ECM pulses the fuel injectors based on information provided by its network of engine sensors. The ECM uses the crankshaft position sensor to determine when to pulse the injectors. Engine coolant temperature, intake air temperature, air flow, and throttle position data are all used by the ECM to calculate injector pulse width.

The ECM also uses its network of sensors to determine whether all injectors should be pulsed at the same time (simultaneous injection) or each injector should be pulsed individually (sequential injection). Sequential injection is almost always used during normal engine operation. Simultaneous injection may be used when the engine is being cranked.


FAILURE CONDITIONS

The ECM will set a code and the MIL will turn on (If installed) if an open circuit or short to ground is detected in the fuel injector circuit during two driving cycles.

CIRCUIT DIAGRAM



TEST PROCEDURE



**CONTINUED ON
NEXT PAGE**

CONTINUED FROM
PREVIOUS PAGE

A

YES

- Ignition off.
- Disconnect fuel injector related to DTC.
- Measure resistance between fuel injector connector terminals 1 and 2.

Resistance should be approximately 15.9 ohms at 68°F (20°C), is it?

YES

Verify ECM connector is secure. If OK, replace fuel injector with known good component. Clear code and verify fuel injector is within normal parameters. If problem persists, replace ECM.

NO

Repair short to ground or another circuit in wire between ECM harness connector terminal 27 [for P0201], terminal 6 [for P0202], terminal 7 [for P0203] or terminal 47 [P0204] and fuel injector harness connector terminal 2.
Clear code and verify fuel injector is within normal parameters.

NO

Replace fuel injector. Clear code and verify injector is within normal parameters.

IFTD5460

DTC	Diagnostic item
P0300	Random Misfire Detected

DESCRIPTION

With the ignition switch at ON or START, voltage is applied to the ignition coil. The ignition coil consists of two coils. High tension leads go to each cylinder from the ignition coil. The ignition coil fires two spark plugs on every power stroke (the cylinder under compression and the cylinder on the exhaust stroke). Coil number one fires cylinders 1 and 4. Coil number two fires cylinders 2 and 3.

The Engine Control Module (ECM) provides a switching circuit to ground for energizing the primary ignition coils. The ECM uses the crankshaft position sensor signal to time the energizing of the coil. When a primary ignition coil is energized and de-energized, the secondary coil produces a high voltage spike across the attached spark plugs.


FAILURE CONDITIONS

The ECM will set P0300 and the MIL will turn on (If applicable) if 2 misfires per 100 revolutions are detected during two driving cycles. The misfire rate is measured every 200 revolutions when the following conditions are met:


- Speed change is less than 1000 rpm per second.
- Engine speed is between 600 and 4000 RPM.
- Engine load is greater than 2 milliseconds.
- No fuel cut-off.
- Starter is not engaged.
- Vehicle on smooth road (acceleration sensor reports less than 0.3 g acceleration).

If the misfire rate increases to between 5%-25% per 200 revolutions, there is danger of catalyst damage and the MIL will flash and on. The catalyst temperature could exceed 3542°F (1950°C) if the misfire rate increases enough. This code indicates a problem with cylinder ignition being read by the ECM.

CIRCUIT DIAGRAM



TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE

A

- Ignition coil connector disconnected.
- Reconnect ECM connector.
- Ignition in start.
- Measure voltage between ground and ignition coil harness connector terminal 1. Note voltage.
- Measure voltage between ground and ignition coil harness connector terminal 2. Note voltage.

Voltage should vary between 0.02 and 0.2 volts, does it?

YES

- Ignition off.
- Disconnect ignition coil connector.
- Disconnect spark plug wires from ignition coil.
- Measure resistance between ignition coil connector terminals 1 and 2. Note primary coil resistance.
- Measure resistance between ignition coil spark plug connector terminals 1 and 4 and between spark plug connector terminals 2 and 3. Note secondary coil resistance.

Primary coil resistance should be approximately 1.0 ohm. Secondary coil resistance should be between 10.3 kilo ohms and 13.9 kilo ohms. Are resistances within specification?

YES

Inspect the following components/systems.

- Spark plugs and spark plug wires needing replacement.
- Fuel injectors for clogging or wiring damage.
- Obstructions to the MAP sensor.
- Acceleration sensor wiring, connection.
- Canister purge valve for normal operation.
- Vacuum hoses for leaks.

Are all components undamaged and within specification?

YES

- Verify fuel pressure according to procedure outlined in shop manual.
- Check engine oil for improper level or contamination (fuel in oil).

Is fuel pressure and oil level within specifications?

YES

Verify ECM connector is secure. If OK, replace ECM. Clear code and verify code does not reappear.

NO

Verify ECM connector is secure. If OK, replace ECM. Clear codes and verify code does not reappear.

NO

Replace ignition coil(s). Clear code and verify code does not reappear.

NO

Repair or replace damaged or out of specification components. Clear codes and verify code does not reappear.

NO

Repair out of specification components. Clear codes and verify code does not reappear.

IFTD5510

DTC	Diagnostic item
P0301	Cylinder 1 Misfire Detected
P0302	Cylinder 2 Misfire Detected
P0303	Cylinder 3 Misfire Detected
P0304	Cylinder 4 Misfire Detected

DESCRIPTION

Refer to DTC P0300.

FAILURE CONDITIONS


The ECM will set P0301, P0302, P0303 or P0304 and MIL will turn on (If installed) if 2 misfires per 100 revolutions are detected during two driving cycles. The misfire rate is measured every 200 revolutions when the following conditions are met:

- No fuel cut-off.
- Starter is not engaged.
- Vehicle on smooth road (acceleration sensor reports less than 0.3 g acceleration).


If the misfire rate increases to between 5%-25% per 200 revolutions, there is danger of catalyst damage and the MIL will flash and on. The catalyst temperature could exceed 3542°F (1950°C) if the misfire rate increases enough. This code indicates a problem with cylinder ignition being read by the ECM.

- Speed change is less than 1000 rpm per second.
- Engine speed is between 600 and 4000 RPM.
- Engine load is greater than 2 milliseconds.

CIRCUIT DIAGRAM



TEST PROCEDURE



IFTD5610

DTC	Diagnostic item
P0335	Crankshaft Position Sensor Circuit Malfunction
P0336	Crankshaft Position Sensor Circuit Out of Range

DESCRIPTION


The Crankshaft Position (CKP) sensor consists of a magnet and coil located next to the flywheel. The sensing wheel teeth are used by the CKP sensor to generate a signal. The voltage signal from CKP sensor allows the Engine Control Module (ECM) to determine engine RPM and crankshaft position.

FAILURE CONDITIONS

(FOR P0335)

The ECM will set P0335 and the MIL will turn on (If installed) if the CKP signal voltage remains at 0.0 volts with the starter engaged for 4 seconds or 8 revolutions and the Camshaft Position (CMP) sensor signal indicating engine rotation. This check is made every time the engine starts.

CIRCUIT DIAGRAM




This code indicates no crankshaft signal is being read by the CKP sensor or the ECM while a CMP sensor signal verifies engine rotation.

(FOR P0336)

The ECM will set P0336 and the MIL will turn on (If installed) immediately if the CKP sensor signal does not indicate the two missing teeth in exactly the same position on the tone wheel during two successive engine revolutions. This check is made for 5 seconds when the engine is running above 2000 RPM. This code indicates a problem with the crankshaft being read by the CKP sensor or ECM.

TEST PROCEDURE



IFTD5660

DTC	Diagnostic item
P0340	Camshaft Position (CMP) Sensor Circuit Malfunction

DESCRIPTION

The Camshaft Position (CMP) sensor senses the Top Dead Center (TDC) point of the #1 cylinder in the compression stroke. The CMP sensor signal allows the Engine Control Module (ECM) to determine the fuel injector sequence starting point.

FAILURE CONDITIONS

(FOR P0342)


The ECM will set P0342 and the Malfunction Indicator Lamp (MIL) will turn on (If installed) if during two driving cycles there is more than one CMP sensor signal during two engine revolutions when the engine speed is above

600 RPM. This code indicates unexpected camshaft position readings by the CMP sensor or ECM when the engine is rotating.


(FOR P0343)

The ECM will set P0343 and the Malfunction Indicator Lamp (MIL) will turn on if during two driving cycles there is no CMP sensor signal within 200 engine revolutions when the engine speed is above 600 RPM. This code indicates unexpected camshaft position readings by the CMP sensor or ECM when the engine is rotating.

CIRCUIT DIAGRAM



TEST PROCEDURE



CONTINUED ON
NEXT PAGE

CONTINUED FROM PREVIOUS PAGE

A

YES

- Ignition off.
- CMP sensor disconnected.
- Measure resistance between ground and CMP harness connector terminal 1.

 Resistance measured should be approximately 1 ohm or less, is it?

NO

Repair short to ground in wire between CMP sensor harness connector terminal 2 and ECM connector terminal 79. Clear code and verify CMP sensor signal is within normal parameters.

YES

- Inspect CMP sensor for debris or misadjustment. Also check engine timing (shop manual section EM).

 Is CMP sensor and timing OK?

NO

Repair open or poor connection between CMP sensor harness connector terminal 1 and ground. Clear code and verify CMP sensor signal is within normal parameters.

YES

Verify ECM connector is secure. If OK, replace ECM. Clear code and verify CMP sensor signal is within normal parameters.

NO

Repair or replace CMP sensor as needed. Clear code and verify CMP sensor signal is within normal parameters.

IFTD5710

DTC	Diagnostic item
P0420	Catalyst System Efficiency Below Threshold (Bank 1)

DESCRIPTION

The catalyst's efficiency is demonstrated in its ability to oxidize CO and HC emissions. The Engine Control Module (ECM) compares the output signals of the front and rear oxygen sensors to determine whether the output of the rear sensor is beginning to match the output of the front oxygen sensor. As the catalyst wears, the rear oxygen sensor's signal trace begins to match the front oxygen sensor's signal trace. That is because the catalyst becomes saturated with oxygen and cannot use the oxygen to convert HC and CO into H₂O and CO₂ with the same efficiency as when it was new. A completely worn catalyst shows a 100% match between front and rear sensor outputs.


FAILURE CONDITION

The efficiency of the catalytic converter is measured by comparing the activity of the front and rear oxygen sensors. The ECM will set a code and the Malfunction Indicator Lamp (MIL) will turn on (if installed) if the front and rear oxygen sensor signals match more than 60% of the time in two of four 170 second monitoring periods during two driving cycles. The measurements are taken when the following conditions are met:

1. The ECM is operating in closed loop.
2. The engine speed is between 1800 and 3200 PRM.
3. The catalyst temperature is above 702°F (372°C).
4. The canister purge function is greater than 0.9.
5. The vehicle is not shifting gears.
6. The engine load is between 1.4 milliseconds and 4.5 milliseconds.

This code indicates that the catalytic converter has been found to have a low efficiency according to the readings of the front and rear oxygen sensors.

TEST PROCEDURE



IFTD5760

DTC	Diagnostic item
P0444	Evap. Emission Control System - PCSV Circuit Open
P0445	Evap. Emission Control System - PCSV Circuit Shorted

DESCRIPTION


The purge control solenoid valve is part of the evaporative emission control system. The solenoid controls purge air from the evaporative emission canister.

FAILURE CONDITIONS

The ECM will set P0444 and the MIL will turn on if an open circuit is detected in the driver stage of the purge control solenoid circuit during two driving cycles.

The ECM will set P0445 and the MIL will turn on if a short circuit is detected in the driver stage of the purge control solenoid circuit during two driving cycles.

TEST PROCEDURE



EFTD5810

DTC	Diagnostic item
P0501	Vehicle Speed Sensor (VSS) Range / Performance

DESCRIPTION

The vehicle speed sensor is a reed switch that is built into the speedometer. The sensor converts the transaxle gear revolutions into a pulse signal which is sent to the ECM.


1. Engine speed is greater than 2200 RPM.
2. Engine load is greater than 3.0 millisecond.

This code indicates no speed signal being read by vehicle speed sensor or ECM.


FAILURE CONDITIONS

The ECM will set a code and the Malfunction Indicator Lamp (MIL) will turn on if there is no vehicle speed sensor output signal for 20 seconds during two driving cycles when the following conditions are met:

CIRCUIT DIAGRAM



TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE



- Turn ignition off.
- Instrument cluster connectors disconnected.
- Ground ECM harness connector terminal 15.
- Disconnect instrument cluster connectors I04-2 and I04-1. Measure resistance between ground and instrument cluster harness connector I04-2 and I04-1 terminal 13 and M71-1 terminal 5. Resistance measured should be approximately 1 ohm or less, is it?

YES

NO

- Instrument cluster connectors still disconnected.
- Rotate speedometer cable.
- Disconnect instrument cluster connectors M71-3 and M71-1. Measure resistance between instrument cluster connector M71-1 terminal 9 and both connector M71-3 terminal 13 and M71-1 terminal 5. Resistance measurement should switch from short to open circuit 4 times per revolution of the shaft, does it?

Repair open in wire between instrument cluster VSS signal terminal and ECM. Clear code and verify VSS signal is within normal parameters.

YES

NO

Verify ECM connector is secure. If OK, replace VSS with known good component. Clear code and verify VSS signal is within normal parameters. If problem persists, replace ECM.

Replace VSS. Clear code and verify VSS signal is within normal parameters.

EFTD5860

DTC	Diagnostic item
P0506 P0507	Idle Control System - Idle RPM Lower Than Expected Idle Control System - Idle PRM Higher Than Expected

DESCRIPTION

Refer to P1510, P1552.


FAILURE CONDITIONS

The ECM will set P0506 or P0507 and the MIL will turn on if for 15 seconds the ISC actuator driver circuit values and engine idle speed are not in agreement with values stored in the ECM during two driving cycles when the following conditions are met:


1. The ISC actuator passes idle air at a rate above 4.1 g/s. [for P0506] or 1.7 g/s [for P0507].
2. Engine speed deviation is below 200 RPM.
3. Vehicle speed is zero.
4. Engine coolant temperature is above 167°F (75°C).

This code indicates the idle speed control actuator and the engine do not agree with the ECM on the idle speed value.

CIRCUIT DIAGRAM



TEST PROCEDURE



CONTINUED FROM
PREVIOUS PAGE

A

- Ignition off.
- ISC actuator connector disconnected.
- Measure resistance between ISC actuator connector terminals 3 and 2.
- Measure resistance between ISC actuator connector terminals 1 and 2.

Resistance should be 10-14 ohms at 68°F (20°C). Are resistance measurements OK?

YES

NO

- Ignition off.
- Check that ISC actuator valve is clean and not sticking.
- Check that throttle lever return spring is clean and not sticking.
- Check intake air system and vacuum hoses to intake air system.

Are the results of these checks OK?

Replace ISC actuator. Clear code and verify code does not reappear.

YES

NO

Verify ECM connector is secure. If OK, replace ISC actuator with known good component. Clear code and verify code does not reappear. If problem persists, replace ECM.

Clean, repair or replace parts as necessary. Clear code and verify code does not reappear.

EFTD5910

DTC	Diagnostic item
P2187	System Too Lean At Idle - Addition
P2188	System Too Rich At Idle - Addition
P2191	System Too Lean At Idle - Multiple
P2192	System Too Rich At Idle - Multiple

DESCRIPTION

The air/fuel control system, in addition to a number of sensors, includes the following components and systems:

- Intake air system.
- Exhaust system.
- Evaporative emissions control system (includes purge control solenoid valve).
- Fuel injectors.
- Fuel pressure regulator.
- Fuel pump.

For the air/fuel ratio to be within limits, all of the sensors, components and systems associated with the air/fuel control system must function within normal parameters.

FAILURE CONDITIONS

(FOR SHORT-TERM FUEL TRIM)

The ECM will set a code and the Malfunction Indicator Lamp (MIL) will turn on if the short-term fuel trim value goes 10% to 15% rich [for P1123] or if the short-term fuel trim additive value is less than 0.4 milliseconds, or 10% to 15% lean [for P1124] for 30 seconds during two driving cycles when the following conditions are met:


1. ECM is in closed loop operation.
2. Engine speed is below 1000 RPM.
3. Engine coolant temperature is above 158°F (70°C).
4. Canister purge system is not operating.
5. Mass air flow is less than 7.5 g/s [for P1123] or 5.5 g/s [for P1124].

(FOR LONG-TERM FUEL TRIM)

The ECM will set a code and the Malfunction Indicator Lamp (MIL) will turn on if the long-term multiplicative value is less than 77% for 30 seconds [for P1127] or if the long-term fuel trim value goes to 10% to 15% lean [for P1128] for 30 seconds during two driving cycles when the following conditions are met:

1. Engine load exceeds 1.8 milliseconds.
2. ECM is in closed loop operation [for P1127].
3. Engine coolant temperature is above 158°F (70°C).
4. Canister purge system is not operating.
5. Mass air flow is less than or 5.5 g/s.
6. Engine speed is below 1000 RPM [for P1128].

TEST PROCEDURE



**CONTINUED ON
NEXT PAGE**

CONTINUED FROM
PREVIOUS PAGE

A

- Ignition off.
 - Inspect fuel pump.
- Is fuel pump OK?

YES

Verify ECM connector is secure. If OK, replace ECM.
Clear code and verify code does not reappear.

NO

Replace fuel pump.
Clear code and verify code does not reappear.

EFTD5960

DTC	Diagnostic item
P1506	Idle Air Actuator Signal High of Coil #1
P1508	Idle Air Actuator Signal High of Coil #2


DESCRIPTION

The Idle Speed Control (ISC) actuator has two coils that are driven by separate ECM driver stages. Depending on the pulse duty factor, the equilibrium of the magnetic forces of the two coils will result in different directions for the magnetic forces of the two coils which will result in different positions for the actuator. In parallel to the throttle valve, a bypass hose line is arranged where the ISC actuator is inserted.


FAILURE CONDITION

The ECM will set a code and the MIL will turn on if ISC actuator's opening coil driver stage [for P1510] or closing coil driver stage [for P1552] is shorted to battery voltage during two driving cycles.

CIRCUIT DIAGRAM



TEST PROCEDURE



EFTD6010

DTC	Diagnostic item
P1505 P1507	Idle Air Actuator Signal Low of Coil #1 Idle Air Actuator Signal Low of Coil #2


DESCRIPTION

Refer to P1510, P1552.


FAILURE CONDITIONS

The ECM will set a code and the MIL will turn on if ISC actuator's opening coil driver stage [for P1513] or closing coil driver stage [for P1553] is open or shorted to ground during two driving cycles.

CIRCUIT DIAGRAM



TEST PROCEDURE



EFTD6060

DTC	Diagnostic item
P1307	Acceleration Sensor Circuit Rationality
P1308	Acceleration Sensor Circuit Low
P1309	Acceleration Sensor Circuit High

DESCRIPTION

The acceleration sensor is used to sense rough road conditions. The sensor's signal is used by the Engine Control Module (ECM) to prevent wrongful misfire detection.

FAILURE CONDITIONS

(FOR P1308, P1309)


The ECM will set a code and the MIL will turn on if the acceleration sensor signal is less than 1.5 or greater than 3.5 volts during two driving cycles. This code indicates

an extremely rough or smooth road being sensed by the acceleration sensor or ECM.


(FOR P1307)

The ECM will set a code and the MIL will turn on if the acceleration sensor signal indicates an acceleration of 0.3g or greater when the vehicle speed is zero during two driving cycles. This code indicates some type of bump being read, with the car speed at zero, by the acceleration sensor or ECM.

CIRCUIT DIAGRAM



TEST PROCEDURE



CONTINUED ON
NEXT PAGE

CONTINUED FROM PREVIOUS PAGE

A

YES

- Acceleration sensor disconnected.
- Ignition off.
- Measure resistance between acceleration sensor connector terminals 2 and 3. Resistance should be approximately 21 kΩ, is it?

NO

Repair short to ground in wire between ECM connector terminal 60 and acceleration sensor terminal 3. Clear code and verify acceleration sensor is within normal parameters.

YES

- Reconnect acceleration sensor connector.
- Reconnect ECM connector.
- Ignition on and engine idling.
- Measure voltage between ground and acceleration sensor harness connector (backprobe) terminal 3. Voltage should be between 2.3-2.7 volts, is it?

NO

Replace acceleration sensor. Clear code and verify acceleration sensor is within normal parameters.

YES

Verify ECM connector is secure. If OK, replace acceleration sensor with known good component. Clear code and verify acceleration sensor is within normal parameters. If problem persists, replace ECM.

NO

Replace acceleration sensor. Clear code and verify acceleration sensor is within normal parameters.