


8. RD250B/RD350B CONNECTION DIAGRAM



- | | | | |
|-------------------------|----------------------------|-----------------------|----------------------------|
| 1. Tachometer | 22. Front flasherlight (L) | 43. Horn | 64. Fuse |
| 2. L | 23. Speedometer | 44. Br | 65. L |
| 3. N | 24. Light checker | 45. P | 66. R |
| 4. Dg | 25. G/W | 46. ACG | 67. Rectifier |
| 5. Br | 26. Ch | 47. Y | 68. R |
| 6. Flasher indicator | 27. Handle switch (L) | 48. Br | 69. W W W |
| 7. High beam indicator | 28. R/Y | 49. P Y | 70. R/W |
| 8. Headlight | 29. Sb | 50. L/W | 71. Regulator |
| 9. R | 30. Handle switch (R) | 51. G | 72. Br |
| 10. R/Y | 31. L | 52. Dg | 73. B |
| 11. L | 32. R/B | 53. B/W | 74. G |
| 12. Br | 33. Br | 54. Ch | 75. Neutral switch |
| 13. L | 34. R/Y | 55. G/Y | 76. Rear stop switch |
| 14. Br | 35. L/W | 56. Front stop switch | 77. Y |
| 15. Main switch | 36. L/W | 57. B/W | 78. Rear flasherlight (R) |
| 16. Stoplight indicator | 37. Br | 58. Dg | 79. Br |
| 17. Flasher indicator | 38. Br | 59. Flasher relay | 80. Taillight |
| 18. G | 39. Br | 60. Battery | 81. Rear flasherlight (L) |
| 19. Y | 40. By | 61. B | 82. Y |
| 20. Ch | 41. D | 62. Br | 83. Dg |
| 21. L | 42. Ignition coil | 63. R | 84. Front flasherlight (R) |
| | | | 85. L/W |

Sb	Sky blue	G/W	Green/White
Dg	Dark green	P	Pink
R/Y	Red/Yellow	Br/W	Brown/White
L	Blue	B	Black
O	Orange	W	White
Br	Brown	R	Red
L/W	Blue/White	G/Y	Green/Yellow
Y	Yellow	R/W	Red/White
G	Green	Gy	Gray
Ch	Dark brown		